

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

920000
DISPLAY STAND

REVISION 0 : 03/12/2018
REVISION 1 : 12/29/2022

ITEM:920000



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 15 MINUTES


PARTS IDENTIFICATION

A LEG



1PC

B HOLDER



1PC

C BOTTOM FRAME



1PC

HARDWARE IDENTIFICATION

1 BOLT
(1/4" x 9mm)



8PCS

3

ALLEN KEY
(4mm)



1PC

2 SUCTION CUP
(ϕ 16 x 9mm)




4PCS

ITEM: 920000 ASSEMBLY INSTRUCTIONS



STEP 1


Do not tighten until each step is completed or instructed.



ITEM: 920000
ASSEMBLY INSTRUCTIONS



STEP 2
COMPLETE




ITEM:920000 ASSEMBLY INSTRUCTIONS



Product Size : 300 X 287 X 1207 H (MM)

Product Size : 11 $\frac{3}{4}$" X 11 $\frac{1}{4}$" X 47 $\frac{1}{2}$"
--



Note : Dimension tolerance $\pm 5\%$