

PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.




A.Right
Chair Arms
3X



B.Left
Chair Arms
3X




C.Backrest
Single Seater
2X



D.Seat
Single Seater
2X



E.Backrest
Loveseat
1X



F.Seat
Loveseat
1X



G.Table Legs
2X



H.Table Top
1X



I.Table Glass
1X




J.Bolt / Washer
42X



K.Allen Key
1X


We stand behind our brand and the quality of the items we sell. We will send new parts, or replace products at our discretion




ASSEMBLY INSTRUCTIONS

Do not fully tighten bolts until assembly is complete.

1. Assemble the chair arms (A) and (B) to the seat (D) (single seater) and the backrest (C) (single seater), using bolts and washer (J).



1. Assemble the table legs (G) to the table top (H), using bolts and washer (J).



2. Assemble the chair arms (A) and (B) to the seat (F) (loveseat) and the backrest (E) (loveseat), using bolts and washer (J).

