

Assembly Instructions

Caution: You must read these Assembly Instructions before you proceed

Care & Maintenance



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- To obtain the longest lifespan of your outdoor product minimizing exposure to direct sunlight is recommended.



- Children should not climb or jump on the furniture.



- Do not write on furniture without a padded barrier to protect the surface.



- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



- Not for commercial use. For residential use only.




- Stains may be removed with mild soap solution and damp cloth.



- Dust and pick-up spills using a clean, non-colored, lint- free cloth.

Dining Chair







Caution: This Chair is NOT a TOY




Keep your child/children at bay during the assembly process.

Whenever lifting or moving the Chair and to prevent damage to the Chair, two adults may be needed to execute these action.

Part List


Label	Picture	Description	Qty
A		Back with Legs	1pc
B		Seat	1pc
C		Front Leg	1pc
D		Stretcher	1pc

Hardware

Label	Picture	Description	Qty
①		Bolt 1/4" x 25 mm	5pcs
②		Bolt 1/4" x 38 mm	3pcs
③		Bolt 1/4" x 55 mm	3pcs
④		Flat Washer Ø6 x 16 x 1.5mm	5pcs
⑤		Allen Wrench 4 x 90mm	1pc
⑥		Wood Cap Ø14 x 7mm	3pcs

Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instruction below to familiarise yourself with the parts and steps before assembly.

Step 1



Unpack and place all parts on a clean, non-marring surface.

Step 2



Place the Seat B facedown onto a clean, non-marring surface.


Attach the Front legs C onto the Seat B. Make sure the hole on the front stretcher is always facing inward. Align them by the tenon on the Front legs, then using the bolts ①+ flat washers ④ and Allen Wrench ⑤ to tighten.

At this step, the bolts are fully tightened (100%).

Step 3

③x 2


⑤x 1



Attach the Back with Legs A onto the Seat B. Align them by tenon on the seat frame. Then Using the Bolt ③ and Allen Wrench ⑤ to tighten.

Do not fully tighten the Bolts at this time.


Step 4



Attach the Stretcher D onto Front Legs C and the Back with Legs A
Using the Bolts ② and Allen Wrench ⑤ to tighten them.


At this step, the bolts are fully tightened (100%).

Step 5



Flip the chair upside down on a flat surface and ensure that all parts are in contact with the surface, then fully tighten all bolts to 100%. Using the Wood Cap ⑥ to cover the Bolts holes on the Back A. Press firmly by hand to ensure they are securely in place and do not fall out.

Step 6



Turn the Chair right side up.

Place the Chair on a **LEVEL SURFACE**.

Inspect it and make sure all parts are adequately connected. Gently and gracefully, sit into to the Chair.

This would help to align all the parts at all the joint areas.

You may required to turn the Chair, to gain easy access to the secure points.

Turn the Chair in a synchronised manner.

CAUTION 1: When tightening these screws, tighten sequentially. **DO NOT** tighten any screw fully and then towards the next one. This would cause the frame to warp.

If there is still wobbles, loosen the screws and execute this same process.

WARNING!! IF CHAIR IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT.

Ensure all screws are fully locked into position.

The Chair is ready to be used.

Caution 2: This Chair can only be used on a flat, level surface.