



# Memory Foam Pillow

Follow these easy steps to enjoy a comfortable pillow in no time

- 1 Unbox your new memory foam pillow and place it in the location you want it to expand.
- 2 Place memory foam pillow on a flat surface in a well-ventilated room and allow it to fully expand **for 48 hours**.

## NOTE

- 1 Due to the unique properties of memory foam, dimensions after expansion may vary, which is normal and will not affect the performance of the memory foam pillow.
- 2 The new memory foam pillow may have a slight odor after unpacking, it is completely harmless and will dissipate quickly after use.
- 3 The memory foam pillow may discolor due to oxidation after long-term use, it is a natural process and will not affect its performance.

# 3-YEAR WARRANTY

## How Long Coverage Lasts

Warranty runs for **three (3) years** from the date of purchase.

## What is Covered

This warranty covers any defects in materials or workmanship, with the exceptions stated below.

## What is Not Covered

The warranty applies only to the original Purchaser within the USA and does not cover: (a) wear and tear; (b) normal changes in softness or resilience (including impressions less than 0.75 inches in depth); (c) stains; (d) misuse or improper maintenance; (e) alteration or repair by unauthorized representatives; (f) damage resulting from transit or handling; (g) commercial use.

## What We Will Do

We reserve the right to repair, replace, or refund any product that proves to be defective in materials or workmanship.

## How State Law Applies

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.