




ASSEMBLY INSTRUCTION



Ax1



Bx1




Cx1



Dx1



Ex4



Fx1



Gx1

STEP 1

Take off the gas lift cap first




B



D

STEP 2




F

E

C

G

STEP 3



A

C

B

D

FINISH

