

ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Allen Wrench

(Included)



Phillips Screwdriver

(Not Included)



3 - People Recommended

ASSEMBLY RATING



EASY ——► DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**

  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Save the instructions and store any supplied tools for later maintenance.





After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

BED


CM7751Q






PARTS

#1 1pc




Headboard

#2 2pcs




Headboard Leg(L&R)

#3 1pc




Headboard Bottom Rail

#4 1pc




Footboard

#5 2pcs




Footboard Leg(L&R)

#6 2pcs



Side rail


#7 4pcs



(Ø1/4")

Slat support leg

#8 4pcs



Slat

HARDWARE

#A 16pcs



Bolt Ø1/4" x 1-3/4"

#B 20pcs




Lock Washer Ø1/4"

#C 20pcs



Flat Washer Ø1/4"

#D 3pcs



Allen Wrench M4

#E 8pcs



Screw M4 x 30mm

#F 4pcs













Bolt Ø1/4" x 2"


#G 12pcs



Bolt Ø5/16" x 1"

CM7751Q is packed in 3 cases

Carton	Disignation	Part		Hardware
CM7751Q-HB	Headboard	#1		 #A x 16pcs  #B x 16pcs  #C x 16pcs  #D x 1pc
	Headboard Leg(L&R)	#2		
	Headboard Bottom Rail	#3		
CM7751Q-FB	Footboard	#4		 #B x 4pcs  #C x 4pcs  #D x 1pc #E x 8pcs  #F x 4pcs
	Footboard Leg(L&R)	#5		
	Slat support leg	#7		
	Slat	#8		
CM7751Q-R	Side rail	#6		 #D x 1pc  #G x 12pcs




ASSEMBLY INSTRUCTIONS

1

Part #1 x1pc
Part #2 x2pcs
Hardware #A x12 pcs
Hardware #B x12 pcs
Hardware #C x12 pcs


Prepare 12 bolts assembly by inserting lock washer (#B), then flat washer (#C) onto bolts (#A). Align HB legs (#2R/L) to the holes of the headboard (#1). Secure by using bolts (#A).



2

Part #3 x1pc
Hardware #A x4 pcs
Hardware #B x4 pcs
Hardware #C x4 pcs

Prepare 4 bolts assembly by inserting lock washer (#B), then flat washer (#C) onto bolts (#A). Align headboard support (#3) to the holes of the headboard legs (#2R/L), then secure by using bolts (#A).




ASSEMBLY INSTRUCTIONS

3

Part #4 x1pc
Part #5 x2pcs
Hardware #B x4 pcs
Hardware #C x4 pcs
Hardware #F x4 pcs


Prepare 4 bolts assembly by inserting lock washer (#B), then flat washer (#C) onto bolts (#F). Align legs (#5R/L) to the holes of the footboard (#4). Secure by using bolts (#F).



4

Part #6 x2pcs
Hardware #G x12 pcs

Attach bolts (#G) half way into the holes of the headboard (#1) and footboard (#4). Align and hook side rails (#6) to the bolts (#G). Secure by tightening bolts (#G).




ASSEMBLY INSTRUCTIONS

5

Part (#7) x4pcs
Part (#8) x4pcs


Attach support legs (#7) to the holes of the slats (#8), then adjust the leveler on the support legs (#7) according to ground level.



6

Hardware (#E) x8 pcs

Align slats to the side rails, secure by using screws (#E).



ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.