




















Egg Swing Chair



Installation Instructions



							
A	1	B	1	C	4	D	1
							
E	1	F	1	G	2	H	2
		 reinforcement				 M-8  M-6	
I	1	J	4	M-8,60mm	1	Hexwrench	
 M-8  M-6		 height adjuster					
Wrench		N	4	M-8,20mm	12	M-6,40mm	4


Step 1:

Screw the 4 height adjusters (N) into the ends of the 4 support legs (C)




Step 2:

Fasten the 4 support legs (C) to the base frame (A) with the reinforcements (J)




Step 3:

Attach accessories (A) and (B) together using screw-M-8,60mm



Step:4


Simply flip the chair base (D) over.



Step:5

Assemble the seat of the chair as shown


--6 (M-8,20mm), 2 (M-6,40mm)



Installation advice: Install the base by placing it on the floor

Step:6

Installation of 6 (M-8,20mm), 2 (M-6,40mm)



Step:7

