

# ASSEMBLY INSTRUCTIONS


## Dining Chair

### ASSEMBLY REQUIREMENTS

1-Person  
Assembly

Assembly Time 30 Minutes  
(Approximate)


Tools Required  
(Not Provided)



### Thank you for purchasing our product!

Please refer and use this assembly instruction to assemble the product.

We appreciate your business!



### ASSEMBLY PREPARATION

- . Remove all packaging materials, staples and packing straps from the carton.
- . Refer to Parts List and Hardware List, and ensure parts and hardware are correct before assembly. Contact customer service for missing parts.
- . Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent scratch and damage to parts.

### SAFETY PRECAUTION

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.








### TIPS FOR ASSEMBLY

- . Allow ample room for assembly and in close proximity to where product will be placed.
- . Assemble the product on a surface that does not scratch or damage the exterior gloss and finish of the furniture.
- . Identify all of the parts, hardware and quantities required for each step.
- . During assembly, do not over-tighten any fittings as this may cause damage.
- . DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
- . Always place the product on a flat, level surface.
- . Do not sit or stand on the partially assembled product; only use the product for which it is intended.

### CARE AND MAINTENANCE

- Use a slightly damp cloth to clean the product. Do not use bleach or abrasive cleaning material.
- Check all the fittings periodically and re-tighten as necessary. Do not use the product if any of the parts is damaged or broken.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or delaminate.
- Do not place hot items (e.g. hot drinks) directly onto the wood surface.
- Do not drag and/or pull the furniture.


This product is for indoor and household use only - not for commercial use.

HARDWARE LIST			EXTRA
A	JCBC M6 x 30mm + S/W M6 + F/W M6 x 13mm 	4PCS	1PC
B	ALLEN KEY M4 (Ball Shape) 	1PC	
C	FH SCREW #8 x 32mm 	4PCS	1PC
D	L BRACKET 	4PCS	
E	PH SCREW M4 x 12mm 	8PCS	1PC
F	WOOD DOWEL M8 x 25mm 	2PCS	1PC
G	PVC NAIL 5/8" (WITH PIN) 	4PCS	1PC

PART LIST		
1	RIGHT SIDE FRAME	1PC
2	LEFT SIDE FRAME	1PC
3	STRETCHER	2PCS
4	TOP REST	1PC
5	CUSHION SEAT	1PC


**\*EXTRA HARDWARE FOR SPARE USE**

## STEP 1




Attach Stretcher (3) to Right Side Frame (1) and Left Side Frame (2). Check that the screw hole on (3) is not facing up.

## STEP 2




- Place assembly from STEP 1 on a flat elevated surface (e.g. table top) as shown to access screw holes on Stretcher.
- Use FH Screw (C) to fasten Stretcher to Side Frames. Use a Phillips screwdriver to drive (C). Do not over-tighten (C).

## STEP 3




- Set assembly from STEP 2 right-side up.
- Position Top Rest (4) to align screw holes on (4) to screw holes on rear leg of each Side Frame.
- Use Screw (A) fitted with Flat and Spring Washer to fasten (4) to upper rear leg of Side Frame.
- Use Allen Key (B) to drive (A). Do not tighten (A) completely until all 4 screws are in place. Do not over-tighten (A).

## STEP 4




- a) Insert Wood Dowel (F) into the designated hole on top rail of Side Frame.

## STEP 5



- a) Place Cushion Seat (5) bottom-side up on a flat elevated surface (e.g. table top) as shown.  
 b) Attach Side Frames to (5) via Wood Dowel (F) on top rail of Side Frame installed in STEP 4.  
 c) Fasten Side Frame to (5) using L-Bracket (D) and Screw (E). Do not tighten (E) completely until all the screws are in place.  
 d) Use a mallet to gently nail PVC Nail (G) to bottom of leg.

## STEP 6



Set the chair right-side up.  
 The assembly of the chair is complete.