

PRE-LIT ARTIFICIAL HINGED CHRISTMAS TREE INSTRUCTION MANUAL





**This instruction applies for
the following items:**




TWO-SECTION TREE












THREE-SECTION TREE

BEFORE YOU START



- ✓ Check your tree box and make sure you have all the tree listed above.
- ✓ When you are ready, make sure you have plenty of space and a clean, dry area to commence.
- ✓ Always assemble your tree as close as possible to the final location.
- ✓ Remove all plastic bags and dispose of them safely.
- ✓ Keep the instructions for future reference.


PARTS

<p>BOTTOM SECTION A ×1</p> 	<p>MIDDLE SECTION B ×1</p>  <p>ONLY FOR THREE-SECTION TREE</p>	<p>TOP SECTION C ×1</p> 
<p>BASE D ×1</p>  <p>90°</p>	<p>BASE SCREW E ×3</p> 	<p>CONTROLLER & CONNECTING CABLE F ×1</p> 
<p>TRANSFORMER G ×1</p> 	<p>PINE CONES & WINTERBERRY H</p>  <p>ONLY FOR NL-H0026</p>	<p>REMOTE CONTROL I ×1</p> 



Wires/plugs may come wrapped around frame pieces.
Locate and unwrap wires/plugs beforehand to make assembly easier.

Please remove the circular protector caps on the end of each of the poles before assembling.



Insider's Tip:
If the plastic plug is too tight to remove, please soften it by hairdryer to remove.


TREE ASSEMBLY

No tools are required for assembly




STEP1 Tree stand assembly:

Open tree stand as shown in Figure. Don't over tighten the screws and make sure bolts are flush with the inside of the stand.



STEP2 Bottom section assembly:

Slot the bottom section of the tree into the tree stand as shown in Figure. Tighten the screws around the bottom pole evenly.



FOR TWO-SECTION TREE


FOR THREE-SECTION TREE

Insider's Tip:

Fluff the bottom branch and test the bottom lights first. Please move on to the column of **SHAPING YOUR TREE & TREE LIGHTS ASSEMBLY**

STEP3 Middle section assembly:

Pull the hinged branches of the bottom section down. Slot the middle sections of the tree into the bottom section as shown in Figure.




FOR TWO-SECTION TREE

FOR THREE-SECTION TREE

STEP4 Tree top assembly:

Lift the top layer of branch tips up to help blend in the top section. Pull the hinged branches of the middle section down. Slot the top section into the middle section of the tree as shown in Figure.



FOR THREE-SECTION TREE

SHAPING EACH BRANCH & TREE

when you unbox your new Christmas tree, you will first notice all the sections of the tree have been compressed for shipping purposes. Fluffing and shaping your tree is a crucial step to make sure your tree looks as full and fluffy as possible.

STEP1 Fan out the tips


At the back of each branch, move each tip straight up or to the side. Each inner tip should resemble a peacock's fanned tail. To hide the trunk, make sure each tip is offset from the one before.



Starting from the back of each branch and fan each group of branch tips evenly to resemble a peacock's tail.

STEP2 Pull out side branches


As you move toward the front of the branch, separate the side branches that shoot off from the main branch. Please note that not all trees have these side branches.



If your branch has sub branches spread at a 45 degree angle.

STEP3 Spread the tips


Continue to separate, shape and arrange each tree tip until the layers of foliage looks as natural and full as possible.



Spread the very front branches to a star shape to resemble a real tree. Follow the same method for the sub branches.

Insider's Tips

- The tree will have some fall out, so keep a dustpan and broom close by to sweep up as you go - something that is especially important when you have kids running around!
- Shape your tree with family and friends - create an experience to remember.
- Fluffing the tree always takes the longest the first time you take it out the box. After the tree has been fluffed once, it will require minimal fluffing subsequent years.



TREE LIGHTS ASSEMBLY

Note: Make sure to first assemble the tree lights before you insert the main plug of the tree into the electricity socket. This plug is located at the bottom of the tree.

STEP1 Bottom section lights assembly

Locate connector on bottom section and match up with connecting cable, for example A-A. Take the remaining connectors and feed up the trunk of the tree. This will make it easier to locate when adding the next section.

STEP2 Middle section lights assembly


Locate connector on bottom section and match up with connecting cable, for example B-B. Take the remaining connectors and feed up the trunk of the tree. This will make it easier to locate when adding the next section.

STEP3 Top section lights assembly


Locate connector on top section and match up with connecting cable, for example C-C. Plug in and test lights.

Insider's Tip:

Match the + pin with the +socket and match the - pin with the -socket(see figure). To secure the connection, make sure to screw the two sides together with the plastic screw cap attached. Attach the connector cable to the transform and plug in to test lights on the bottom section.




DECORATION ASSEMBLY



It's always a pleasure to decorate pine cones and Winterberry. find the branches and leaves where you want to insert the pine cones and Winterberry. tie the ends of the wire attached to the pine cones to the branches and leaves. and insert the Winterberry and leaves into the nearby branches and leaves. This is shown in Figure.

REMOTE CONTROL INSTRUCTIONS

- Before use, insert CR2025 3V Lithium Coin Cell Battery observing the polarity markings inside the battery compartment.
- All multi-color, pre-lit models include a wireless remote control and convenient foot remote connected to the power cord. Both allow you to control your tree's display by alternating colors and patterns at the touch of a button. When using the remote control, remember to aim the controller for remote control. The range of remote control is within 5 meters.



FUNCTION LIST

- 1 Auto Repeat
- 2 Color 1 Constantly On
- 3 Color 2 Constantly On
- 4 Color 1 Slowly Flashing
- 5 Color 2 Slowly Flashing
- 6 Colors 1 and 2 Alternately Flashing
- 7 Colors 1 and 2 Slowly+Twinkle Flashing
- 8 Colors 1 and 2 Slowly Flashing
- 9 Colors 1 and 2 Slowly Fading

● Default Timer Function:

Click Timer to open timer mode. Lights stay ON for 8 hours and then turn OFF for 16 hours. Timer function will restart when any control button is pressed or main power supply to the lights is reconnected.

- There are 5 brightness levels. Simply press the controller buttons to increase ☀ or decrease ☀ the brightness to your liking.

SAFETY INSTRUCTIONS

- This tree is not a toy and must be used for decorative purposes only.
- Choking Hazard - Small parts may be generated. Keep out of reach of children and pets.
- Suffocation Hazard. Remove all plastic and dispose of them safely. Keep out of reach of infants and children.
- Always position your tree, cables and extension leads so that they are not a hazard to children, elderly and pets.
- Position your tree on a surface that will not get damaged by the tree or if decorations detach. Position your tree on a level surface.
- This tree is intended for indoor use only.

STORAGE INSTRUCTIONS

To retain the beauty of your artificial Christmas tree, it is especially important to store it properly. To prevent any damage, make sure you store your tree in a cool, dry place. We recommend using the original box to keep your tree in great condition for years to come.

- Carefully detach the light connectors from each section of the tree. Ensure to unplug the lights.
- Consider moving the storage box and individual tree sections separately to your final storage location.

Caution :

This step is to minimize heavy lifting. Heavy lifting can cause muscle strain and back injury. Should you need to move your tree box, be sure to use proper lifting techniques when moving.

- Flatten each tree section so that it will fit more easily into your storage box.
- Be sure to store your tree in a cool, dry location to prevent it from acquiring a musty odour while in storage.

Insider's Tip :

As an extra precaution to eliminate the chances of your tree acquiring a musty odour, store the Tree with a container of baking soda. The baking soda will absorb excess moisture and odour, and leave your tree smelling much fresher.