



# USER MANUAL


## Installation Guide for Smart Electric Recliner



CustomerSupport:Info.amerlifelifehome@gmail.com






Warning: Do not exceed the listed maximum weight.  
Serious personal injury or property damage may occur!









# INSTALLATION

## Parts List


|                                                                                                |                                                                                                |                                                                                                |                                                                                                |
|------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|
| <b>01</b><br> | <b>02</b><br> | <b>03</b><br> | <b>04</b><br> |
| Backrest                                                                                       | Seat Cushion                                                                                   | Left Armrest                                                                                   | Right Armrest                                                                                  |
| <b>05</b><br> | <b>06</b><br> |                                                                                                |                                                                                                |
| Left Back Ear*1                                                                                | Right Back Ear*1                                                                               |                                                                                                |                                                                                                |

## Hard Ware


|                                                                                     |                                                                                     |                                                                                     |                                                                                     |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
|  |  |  |  |
| A: Foot*2                                                                           | B: Power Adapter*1                                                                  | C: Controller*1                                                                     | D: M6*40mm*4<br>+1 (spare)                                                          |
|   |  |  |                                                                                     |
| E: wrench*1                                                                         | F: *4<br>+1 (spare)                                                                 | G: 3/16" (5mm)*1                                                                    |                                                                                     |




BOX A




01 X1




03 X1




04 X1




BOX B ( Hardware kit contained in this carton )




02 X1



05 X1



06 X1



Hardware



A:x2



B:x1



C:x1



D:x5



E:x1




F:x5




G:x1


1




2





**Fasten the buckle on the backrest and the insert piece on the seat cushion as shown in the figure.**



4









Electric Massager


Sitting position



TV reclining position



Lying position



Standing position





Power Input  
100V-240V



Max Load  
300 lbs / 136kg



2 Person  
Assembly



Only the occupant or a responsible adult should operate the chair.



Do not exceed the maximum weight capacity, as this may cause serious injury or property damage.



After use, always return the chair to the upright position.



Keep hands and body parts away from the recliner mechanism while it is in motion.



Do not place objects under the chair. Ensure it is clear of obstructions before operation.



Do not allow children to play with or operate the chair. Children must be supervised at all times.



Do not allow anyone to sit on your lap, the chair arms, or the recliner mechanism while in use, as this may cause tipping and injury.



Excessive force, rough handling, or dropping can significantly reduce the chair's lifespan.




Do not suddenly drop into the chair when sitting.



Make sure there is enough space for the chair to fully recline.



## Manuelle Steuerung Bedienungsanleitung



- ▲ : Long press this button; the sofa will unfold slowly.
- ▼ : Press and hold this button, the sofa retracts and rises gradually to assist standing up.
-  : Tap this button, and the sofa will automatically return to the seating position.
-  : Tap this button, the sofa automatically adjusts to the TV posture.
-  : Tap this button, and the sofa will automatically move to the recline position.
-  : Tap once to turn on the massage function, and the ON indicator light will illuminate. Tap again to turn off the massage function, and the OFF indicator light will illuminate. (Lights will turn off automatically if no operation within 10 seconds.)
-  : Tap once, the "15min" indicator lights up, and the massage will automatically shut down after a 15-minute timer. Tap again, the "20min" indicator lights up, and the massage will automatically shut down after a 20-minute timer. If no indicator is lit, the massage will turn off automatically in 30 minutes by default after being activated with no timing setting.
-  : Tap once to light up the "L" indicator for the reciprocating massage mode; tap again to light up the "H" indicator for the continuous massage mode.

**Reset operation:** Press and hold Button  and Button  simultaneously until the sofa starts to unfold and reset. Once the reset is finished, the sofa will automatically return to the seating position.