Finial Shade Harp Saddle Socket Assembly Lamp body


ASSEMBLY INSTRUCTIONS

ASSEMBLE IT BY FOLLOWING STEPS.

- 1. Fasten The Socket Assembly Onto The Lamp body. Becareful not TO Twist The Power Cord.
- 2. Insert The harp Into The saddle.
- 3. Place The Shade Onto The harp And Tighten The finial.
- 4. Please Use 150W Bulb (Bulb not Included)

IMPORTANT SAFETY INSTRUCTIONS

CAUTION: THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER), AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK, THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY, IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG, IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN, NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED, DO NOT ALTER THE PLUG.



ASSEMBLY INSTRUCTIONS

ASSEMBLE IT BY FOLLOWING STEPS .

- 1. Fasten The Socket Assembly Onto The Lamp body. Becareful not TO Twist The Power Cord.
- 2. Insert The harp Into The saddle.
- 3. Place The Shade Onto The harp And Tighten The finial.
- 4. Please Use 150W Bulb (Bulb not Included)

► Socket Assembly IMPORTANT SAFETY INSTRUCTIONS

CAUTION: THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER), AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK, THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY, IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG, IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN, NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED, DO NOT ALTER THE PLUG.