



# Installation instructions


## 1 Timing adjustment



## 2 Clean Surface



## 3 Connect components



## 4 Choose the Sensor installation position

