






















Installation instruction


17
11
16
12
14
16
1
13
12
1
3
15
2
6
6
4
4
5
5
6
6
10
10
2
10
10
3
7
7
9
9
8
8

Parts and Operation Elements

			
① 2pcs	② 2pcs	③ 2pcs	④ 2pcs
			
⑤ 2pcs	⑥ 2pcs	⑦ 2pcs	⑧ 2pcs
			
⑨ 2pcs	⑩ 4pcs	⑪ 1pcs	⑫ 2pcs
			
⑬ 1pcs	⑭ 1pcs	⑮ 1pcs	⑯ 2pcs
			
⑰ 1pcs			


Hardware

 Cam bolt		 Cam Lock		 6x30mm Wood dowel		 4x35mm screw		 3x12mm screw	
A	48pcs	B	48pcs	C	32pcs	D	4pcs	E	32pcs
									
F	8pcs	G	8pcs	H	8pcs	J	2pcs	K	12pcs
 3.5x12mm screw									
L	12pcs								




SPARE BAG

THE SPARE BAG INCLUED EXTRA HARDWARE FOR DAMAGED OR MISSING SMALL HARDWARE WHILE YOU ARE ASSEMBLING



1


A x12



x2

2


B x12



x2

3


A x8




x2

4


A x8



x2



5
B x8
C x4
9
7
2
8
C
B
6
B x8
C x4
3
9
7
2
8
C
B
x2
x2

7




x2


8




x2


9
A x12
A
A
A
A
A
A
A
1
x2
10
B x12
C x12
1
C
C
B
B
2
C
C
B
4
B
C
C
B
B
3
1
C
4
B
x2

11



12




13

G x8


H x8


E x32





x4

14













x2

15











x2


16




17




18



19







20

B x4


C x4




21




22






To adjust the vertical height.
Loosen the four screws "A" on both hinges.
Two of them are usually in slotted holes which allows you to adjust up or down by a few mm.
Then tighten back up.




To adjust depth.
Loosen screw "B" and adjust door, if the door can not be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C".




To adjust side ways.
Turning the screw "C" on BOTH hinges on each door.


23




24

K x12







25

