











Model: ZWJ414-280-BK-LP, ZWJ414-280-BK




Please scan the QR code to watch the tutorial video

https://www.youtube.com/@furnishglow/videos

Parts List:


A 2pcs 	B 2pcs 	C 1pcs 
D 1pcs 	E 2pcs 	F 2pcs 
G 4pcs 	H 1pcs 	I 1pcs 
J 2pcs 	K 2pcs 	L 2pcs 
M 8pcs  M8*10mm	N 8pcs  M8*35mm	O 8pcs 

Parts List:


P 4pcs  M6*35mm	Q 4pcs  M6*10mm	R 4pcs  M4*10mm
S 2pcs  M4*30mm	T 1pcs 	U 1pcs 


ASSEMBLY

STEP 1




STEP 2







STEP 3


I
H
On the outside
E
E
T
O x4
N x4
M x2
M8*35mm
M8*10mm
P x2
M6*35mm
M x2
M8*10mm
P x2
M6*35mm


STEP 4


C
Q x4
M6*10mm

STEP 5




STEP 6



Press these spring pins to adjust the table length

STEP 7



Adjustable Anti-Collision Pads

STEP 8

