




I870101851A1



Tools required
(not included)



2 people for assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



power drill is set on a low torque setting.

- To reduce the likelihood of damaging your product please ensure that your

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

please note that only the anti tip strap is provided.

You will need to provide wall plugs and screws applicable for your wall type


Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.

4



WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:


- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.













This is a permanent label.
Do not remove!

Important Notice:





If you encounter any issues with the product, we kindly request you to promptly contact the customer service of the store on Amazon. Specifically, if you need to initiate a product return, please reach out to the customer service for assistance. We are dedicated to prioritizing your needs and will efficiently process refunds or arrange for reshipments as necessary. It is important to note that selecting the return address provided on the backend may not be suitable for receiving returns, so we advise against using it directly.




Parts List

①  3 pcs	②  4 pcs	③  4 pcs	④  2 pcs
⑤  2 pcs	⑥  1 pc	⑦  1 pc	⑧  2 pcs
⑨  2 pcs	⑩  2 pcs	⑪  2 pcs	


Hardware List

 φ6×35mm	 φ15×10mm	 M6×10mm	 M6×22mm
Ⓐ×8pcs+2pcs	Ⓑ×8pcs+2pcs	Ⓒ×30pcs+2pcs	Ⓓ×20pcs+2pcs
 Ø6×30mm	 φ5×37mm		
Ⓔ×14pcs+2pcs	Ⓕ×8pcs+2pcs	Ⓖ×1pc	Ⓗ×1pc
	 M3	 M4	
Ⓢ×1pc	Ⓣ×1pc	Ⓚ×1pc	Ⓛ×1pc
			
Ⓜ×4pcs			



STEP 1



STEP 2






STEP 3





 M6×10mm		
Ⓒ×8pcs	Ⓔ×1pc	Ⓕ×1pc

STEP 4





 M6×22mm
Ⓓ×8pcs

STEP 5






M6×10mm
©×4pcs

STEP 6







M6×10mm
©×2pcs

STEP 7






M6×10mm
Ⓢ×8pcs

STEP 8






M6×10mm
Ⓢ×8pcs



STEP 9



STEP 10





STEP 11




Ⓐ × 8 pcs

STEP 12




Ⓕ × 4 pcs


STEP 13



STEP 14



STEP 15



STEP 16

