



INSTRUCTION MANUAL




GENERAL ASSEMBLY GUIDELINES


- I . Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. A Phillips head screwdriver is required for the assembly of this product.



- V. Power tools should not be used to assemble this product.



PARTS LIST






ACCESSORIES LIST

PART	IMAGE	DESCRIPTION		QTY
A			Cam Lock	70 PCS
B			Cam Lock	70 PCS
C		Ø4*12	Screw	6 PCS

The hardware quantities listed above are required for proper assembly, Some extra hardware may also have been included.


ANTI-TIP KIT

PART	IMAGE	DESCRIPTION		QTY
AA			Mounting Bracket	2 PCS
AB			Anchor	2 PCS
AC			Nylon Strap	1 PCS
AD	+ 	Ø4*15	Flat Head Screw	2 PCS
AE	+ 	Ø4*30	Flat Head Screw	2 PCS

The hardware quantities listed above are required for proper assembly, Some extra hardware may also have been included.


STEP 1

A  x2




STEP 2

B  x2




STEP 3

A  x7




STEP 4

B  x7




STEP 5

A  x13




STEP 6

B  x7




STEP 7

A  x4




STEP 8

B  x4




STEP 9

B  x6




STEP 10




STEP 11

A  x10



STEP 12

B  x6




STEP 13

B



×4




STEP 14

A




x4




STEP 15

B  x4




STEP 16

A  x17




STEP 17

B  x7




STEP 18

A  x2




STEP 19

B  x2




STEP 20

B  x10




STEP 21

A  x9




STEP 22

B  x9




STEP 23





Note: Screws are provided at fireplace parts package. Please follow the fireplace manual.

STEP 24




STEP 25



Note: Screws are provided at fireplace parts package. Self-tapping screws can easily penetrate the wood board, please tighten them directly.


STEP 26



Note: Adjust the cabinet to the appropriate position.

Assembly

Anchoring the media console



Care and maintenance



Do not use abrasive or chemical cleaners. Discolouring or damage to finish may result.

Clean media console with a non-abrasive cloth. Clean as often as necessary.

NOTE:

Excessive sun exposure may cause discolouring or fading of media console finish.