

ASSEMBLY INSTRUCTION SHEET



IF YOU PURCHASED THE CHRISTMAS TREE ONLINE AND HAVE ANY QUESTIONS OR CONCERNS PLEASE CONTACT US WITH EMAIL OR TEXTEMAIL: yardsightfurniture@outlook.com
TEXT: +1 323-400-0363

WARNING:




1. Read all instructions and warning tags included with this tree. Retain for future reference.
2. Ensure all packaging is removed before assembly and use.
3. Keep tree's light sets unplugged from power before beginning assembly.
4. Keep wires clear of being pinched or cut during assembly and use.
5. Ensure final assembly is upright and stable.
6. Do not use candles on tree.
7. Do not use near candles, fireplaces, radiators, or other similar sources of heat.
8. Do not use near tubs, sinks, or other wet areas.
9. Artificial trees are made from small fibers that may pose a choking hazard if detached from the branches. Use care around children and pets.

Before you start:

These instructions will guide you on how to set up your tree to ensure it is fully functioning and looking its best. This guide will also give you tips on how to store your tree to last for years to come. Please read the following instruction carefully before you start.

Remember to save the carton for storage of your tree

1. Each tree section contains a tag labeled A, B and C. Please identify all sections before assembling.
2. Remove the tree sections from the packaging before beginning and keep the carton for future storage.
3. Select an area where the ground is firm enough to hold the tree upright.
4. If you are having difficulties with any of the tree components, 2-person assembly is recommended.
5. Take out the tree stand, unfold it, and insert the eye bolts. Remove the packing materials from the end of poles. Put the bottom section pole into the tree stand and make sure it is inserted properly as in Fig.1.
6. Continue by inserting the upper tree section into the lower section until inserting the treetop. Make sure the tree is stable and upright. Tighten eye bolts evenly to ensure tree does not lean too far to one side.
7. Each tree section has a light string cord that will plug into a receptacle on the section below. Note that the male and female connectors are keyed and will only connect in one direction. After connection, twist and close each connector nut securely. Find the power cord at the bottom sections connect the electrical cord at the base of tree into a standard electrical outlet or other power sources. seen in Fig. 2.
8. To shape the tree please refer to Fig.3. All hinged branches should fall into lower position during assembly. Any branches that remain upright should be gently lowered by hand.



Storage Tips:

1. Remove all decorations.
2. Starting from the top, carefully press each tip against each branch, and then fold them towards the main stem.
3. Store the carton on a flat surface in a cool and dry environment.
4. Do not store the tree in a damp area or where temperatures can reach over 100 degrees Fahrenheit.

The Lights on this tree are non-replaceable LED bulbs.

Plug the transformer into an indoor light socket and switch on the main supply.