
Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance				
Ø =	Not for commercial use. For residential use only.			
0 1	Furniture may scratch floors. We recommend using furniture pads to protect your floors.			
⊘ <u></u>	Do not put hot items directly on furniture surface.			
Ø 🖺	Do not clean furniture with harsh cleansers or polish.			
Ø 🔅	Do not place furniture under direct sunlight.			
0	Do not place furniture near heating or cooling vents.			
Ø L	Do not write on furniture without a padded barrier to protect the surface.			
Ø	Do not place furniture outside . For indoor use only.			
Ø	 Stains may be removed with mild soap solution and damp cloth. 			
Ø %	Children should not climb or jump on the furniture.			
,0	Dust and pick-up spills using a clean, non-colored,			

lint-free cloth.

Sofa



Part List

Label	Picture	Description	QTY
Α		Backrest	1
В		Left Armrest	1
С		Right Armrest	1
D		Seat	1

E		Front Rail	1			
F		Seat Cushion	2			
G		Leg	4			
Hardware List						
Label	Picture	Description	QTY			
(\$)	₩	Plastic Washer	5			
•		Allen Wrench	1			
Assembly Preparation						
Before Beginning Assembly:	*4 *5 *1					



Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-



Save all packaging until finished-

Assembly Steps


OVERVIEW



This Sofa has multiple parts and may require up to 60 minutes to assemble. To give you an overview of the Sofa parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Note: It is recommended that you have an adult partner to assist during the entire assembly process.

Step 1




Open the carton and place all the parts on a clean, non-marring surface.

LOOSEN the 3 bolts in Left Armrest(B) around half inch by Allen Wrench(2).


Repeat the same step to loosen 3 bolts in Right Armrest(C).

Step 2



With the assistance of your partner, slide the hook in the eng of Front Rail(E) into the bolts on the Left Armrest(B) and Right Armrest(C), as shown in Picture 1.

Step 3




Slide the Tapered Connectors on the Backrest(A) into the Tapered Connectors on the Left Armrest(B) and the Right Armrest(C) as shown above.

Note: Make sure the Tapered Connectors on Backrest(A) lock into the Tapered Connectors on the Left Armrest(B) and Right Armrest(C).

Assistance from an adult partner is necessary for this assembly process.

During this assembly process - do exercise caution. You may need to use your hand to press down and or pave away the padded surface to facilitate the 'slip and slide' assembly.


Caution: Ensure that your fingers do not get caught or pinched in the assembly process.



With the assistance of your partner, lift the rope on the two sides of Seat Panel(D) by hand.

Put the Seat Panel(D) on the wood bar of the Front Rail(E) and then slowly place it down as shown above.


Note: All the u-shaped iron sheet need clamped to the bolt.



Install the Leg(F) into the bottom of Left Armrest (B) and Right Armrest(C) by placing Plastic Washer(©) on the threaded stem. Then insert threaded stem into the threaded mounting postion at the bottom of Left Armrest(B) and Right Armrest(C).


Note: The use of Plastic Washer(⑤) are OPTIONAL and are especially useful to help alleviate slight wobbles. Some Legs may need more than one whilst some legs may not need any.

Step 6



Put the Seat Cushion(F) on the sofa

Step 7



Your Loveseat Sofa is ready for use. This Sofa can only be used on a flat, level surface.