

Plug Configuration



WCT805B
NEMA 5-20P



WCT815B - WCT825B
NEMA 6-15P

WARING

COMMERCIAL

208 Volt Toasters

WCT805B
Four 11/8" Toast Slots

WCT815B
Two 11/8" Toast Slots
Two 11/2" Extra Wide Slots


WCT825B
Four 11/2" Extra Wide Slots

Unit Information

WCT805B
Amps 13 • Watts 2700


WCT815B
Amps 10 • Watts 2025

WCT825B
Amps 7.25 • Watts 1500





Toaster Components WCT805B • WCT815B • WCT825B



Catalog/Model

WCT805B

WCT815B

WCT825B

Waring Factory Service Center
314 Ella T. Grasso Ave.
Torrington, CT 06790
Tele. 1-800-269-6640

Fax 860-496-9017
www.waringcommercialproducts.com

Illustration #	Part #	Description
1	027219 027169 029825	WCT805B Top Cover Plate WCT815B Top Cover Plate WCT825B Top Cover Plate
2	027170	Push Knob (flat outer center 2 required)
3	027171	Push Knob (screw hole in outer center 2 required)
4	027172	Screw (2 required)
5	027173	Set Screw (2 required)
6	027174	Browning Control Knob
7	027175	Crumb Tray
8	033463 027220	WCT805B Cord Set WCT815B – WCT825B Cord Set
9	027177	Screw (4 required)
10	027178	Foot (4 required)
11	027179	Rubber Foot (4 required)
12	027180	Washer (4 required)
13	027181	Screw (4 required)
14	502939	Front Panel Assembly
15	027177	Screw (2 required)
16	027182	Front Cover Plate
17	027183	Back Cover Plate
18	027184	Power Box Cover
19	027177	Screw (4 required)
20	027185	Housing Support (2 required)
21	027186	Screw (4 required)
22	027187	Compression Wire Spring (4 required)
23	027188	Moving Bracket Spring (2 required)
24	027189	Bracket Bushing (8 required)
25	027190	C Ring (4 required)
26	502940 502940	WCT805B Moving Bracket Assembly (2 required) WCT815B Moving Bracket Assembly (1 required)
26a	502941 502941	WCT815B Moving Bracket Assembly (1 required) WCT825B Moving Bracket Assembly (2 required)
27	027191	Damper Cylinder Rod (2 required)
28	027192	Locking Mechanism
29	027193	Screw (4 required)
30	034768	Screw (4 required)
31	034767	Switch Cover (2 required)
32	034769	Screw (8 required)

Catalog/Model

WCT805B

WCT815B

WCT825B

Waring Factory Service Center
314 Ella T. Grasso Ave.
Torrington, CT 06790
Tele. 1-800-269-6640

Fax 860-496-9017
www.waringcommercialproducts.com

Illustration #	Part #	Description
33	033456	Micro Switch (4 required)
34	027198	Rheostat (2 required)
35	027199	Insulated Bracket Plate (2 required)
36	027200	Screw (4 required)
37	027902	WCT805B Elements 17-7270 (8 required)
	027902	WCT815B Elements 17-7270 (6 required)
	033534	WCT825B Elements 17-4008 (4 required)
38	027202	Screw (16 required)
39	027203	Ceramic Insulator Bracket (16 required)
40	027204	Hex Nut (16 required)
41	027205	Hex Nut (16 required)
42	027206	Screw (16 required)
43	027207	Jumper Bracket
44	027947	Standard Slot Baffle
	027946	Wide Slot Baffle
45	027943	WCT805B PC Board (2 required)
	027945	WCT815B Toast Side PC Board
46	027944	WCT815B Bagel Side PC Board
	027944	WCT825B PC Board (2 required)
47	027209	Screw (4 required)
48	027210	Screw (2 required)
49	027211	Ground Lock Washer
50	027212	Green Ground Screw
51	027213	Screw (2 required)
52	027214	Power PCB Holder (2 required)
53	027215	Hex Nut (4 required)
54	027216	Power Terminal Board
55	027224	Strain Relief
56	027177	Screw (2 required)
57	027218	Power Box Body
58	027225	Bottom Cover

Items Not Shown

027214

PC Board Main PCB Holder (4 required)

027222

Front Panel Assembly Screw (5 required)

Parts No Longer Used

