









ASSEMBLY INSTRUCTIONS



FLOOR LAMP

Thank for your purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.



HARDWARE LIST			
A		LAMP BASE	01
B		STEM WITH SHADE	01
C		KNOB WITH STUD	01
D		KNOB	01
E		SET SCREW	01
F		ALLEN KEY	01
G		BULB (Not Included)	01

ASSEMBLY INSTRUCTIONS
FLOOR LAMP



921MM

1449MM

ASSEMBLY INSTRUCTIONS

FLOOR LAMP

IMPORTANT SAFETY INSTRUCTIONS:

1. This fixture has been rated for 40 - Watt maximum Type B standard bulb.
2. To avoid the risk of fire, do not exceed the recommended wattage.
3. The manufacturer and distributor accept no liability for incorrect installation.
4. For indoor use only.

WARNINGS:

1. Turn - off / unplug and allow to cool before replacing bulb (lamp).
2. Do not touch bulb or look directly at lighted lamp.
3. Keep flammable materials away from light bulb.

THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.

STRANGULATION HAZARD

Keep cord at least 3 feet away from cribs, bassinets, and toddler beds.
Keep out of reach of children under 3 years of age.