



## INSTRUCTION MANUAL

Loosely assemble before tightening.  
IF YOU PURCHASED THE THREE-SEAT SOFA ONLINE AND HAVE ANY  
QUESTIONS OR CONCERNS  
PLEASE CONTACT US VIA EMAIL, TEXT, OR PHONE








EMAIL: [service2outdoor@gmail.com](mailto:service2outdoor@gmail.com)  
TEXT: +1 628-263-4608 (TEXT ONLY)  
PHONE: +1 877-561-6450  
Warranty period: 180 days

Lost accessories or parts costs will be incurred after 90 days of the date of purchase.





# Assembly Instruction



# PARTS LIST


<p>①</p>  <p>1PC</p>	<p>②</p>  <p>1PC</p>	<p>③</p>  <p>1PC</p>
<p>④</p>  <p>1PC</p>	<p>⑤</p>  <p>3PC</p>	<p>⑥</p>  <p>3PC</p>
<p>⑦</p>  <p>1PC</p>		

# HARDWARE LIST

<p>A</p>  <p>M8x50mm 6PCS</p>	<p>B</p>  <p>M8x60mm 2PCS</p>	<p>C</p>  <p>1PC</p>	<p>D</p>  <p>5PCS</p>
--	--	---	--

# STEPS



**STEP-1**  **D x 5PCS**



## STEPS



### STEP-2



You need to unplug the canes and insert the screws if the canes block the assemble hole.



# STEPS


## STEP-3

	A x 2PCS
	C






# STEPS



## STEP-4



# STEPS


## STEP-5

	A x 1PC
	B x 1PC
	C






# STEPS



## STEP-6



# STEPS


## STEP-7

	A x 3PCS
	B x 1PC
	C



# STEPS

## STEP-8



# STEPS

## STEP-9

