



STEP 1

- 1a. Install 4 adjustable feet or 4 casters on the base as needed;
- 1b. Fasten the locking screws with provided wrench.




STEP 2


Attache the pole to the base.



STEP 3


Install the middle shelf support and attache the leveler (Part #G).



NO.	DESCRIPTION	Q'TY
A	 M6x8mm	2
B	 M6x15mm	7
C	 M8x42mm	3
D	 M4x15mm	4
E	 Ø25/Ø8.2x2.0	3
F	 M4 +  M5 +  M14	1set
G	 M6x12mm	2
H	 Ø25	4
I	 Ø23xM6x18mm	2
J	 Ø58xM8	4
K		4
L		1
M		1
N		1
O		2
P		1
Q		1


STEP 4

Attache the mounting bracket (Part #N) to the pole.




STEP 5

Install the middle glass shelf.




STEP 6

Secure the barckets(Part #O) on the back of the TV with 1 spacer,1 washer and 1 screw for each bracket as shown in the diagram.



STEP 7


Hang the TV to the mounting bracket.



NO.	DESCRIPTION	Q'TY
S1	M4x12mm 	4
S2	M5x12mm 	4
S3	M6x12mm 	4
S4	M8x15mm 	4
S5	M4x32mm 	4
S6	M5x32mm 	4
S7	M6x32mm 	4
S8	M8x32mm 	4
S9	Ø19xØ6.2mm 	4
S10	Ø22xØ8.2mm 	4
S11	Ø14x14mm 	4
S12	Ø25x13mm 	4
S13	Ø25x2mm 	4

STEP 8

Secure the 2 knobs to the bracket.



STEP 9

Install the cable management guides.

