





Product Instruction






IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.





AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer—could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.













Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.




Note:


1. 50% Tighten before fixing all screws, Allen wrench is recommended instead of an electric drill.
2. Place the item on a flat ground to adjust and make sure it remains stable.
3. Tighten up all screw with tools gradually .
4. If screw are not aligned with holes during assembly , please loosen all the other screws to 50% and continue the assembly process.
5. If the item is not stable, please loosen all screws, adjust it on a flat ground and tighten up all screws again.
6. Note: If one or some screws are fully tighten during assembly , chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.

CARTON CONTENT :






①  1PC	②  1PC	③  1PC	④  1PC
⑤  1PC	⑥  1PC	⑦  1PC	⑧  1PC
⑨  2PCS	⑩  3PCS	⑪  1PC	⑫  1PC
⑬  1PC	⑭  1PC	⑮  4PCS	⑯  1PC




Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size


A	X15		M6x35mm
B	X15		
C	X1		4mm
D	X15		
E	X24		M5x40mm
F	X6		M6x22mm
G	X14		M6x12mm
H	X1		
I	X16		M4x14mm
J	X4		

1



A	X4
	
M6x35mm	


2



E	X4
	
M5x40mm	


D	X2
	

3



A	X4
	
M6x35mm	



4



B	X4
	

D	X2
	

5




E	X2
	
M5x40mm	

B	X4
	

D	X3
	


6




I	X16
	
M4x14mm	

J	X4
	

7




8




E	X4	D	X2
			
M5x40mm			

9




D	x4
	

10




E	x10
	
M5x40mm	


11



12




13



A	X3
	
M6x35mm	


14



B	X3
	


E	x2
	
M5x40mm	

15




E	X2
	
M5x40mm	

16




G	X2
	
M6x12mm	

17




18




A	X4
	
M6x35mm	

19



20




The bottom holes of H1 and H2 are oval holes.
Do not tighten the screws directly.
You can adjust the panel height here.
After confirming the position,
tighten them together.

Die unteren Löcher von H1 und H2 sind oval.
Ziehen Sie die Schrauben nicht direkt fest.
Hier können Sie die Höhe des Panels einstellen.
Nachdem Sie die Position überprüft haben,
ziehen Sie die Schrauben fest.

Les trous inférieurs de H1 et H2 sont ovales.
Ne serrez pas les vis directement.
Vous pouvez ajuster la hauteur du panneau ici.
Après avoir vérifié la position,
serrez-les ensemble.

H	x1	G	x8
			
		M6x12mm	

21



The upper holes of H1 and H2 are oval holes. Do not tighten the screws directly. You can adjust the front and back of the panel here, and tighten them together after confirming the position.

Die oberen Löcher H1 und H2 sind oval. Ziehen Sie die Schrauben nicht direkt fest. Sie können die Vorder- und Rückseite der Platte hier justieren und sie erst nach Überprüfung der Position festziehen.

Les trous supérieurs de H1 et H2 sont ovales. Ne serrez pas les vis directement. Ajustez d'abord l'avant et l'arrière du panneau, puis serrez-les ensemble après avoir vérifié la position.

G	X4
	
M6x12mm	

22

