



Hammock Chair

Assembly Guide



PARTS LIST

- (1) Hammaka Chair with Footrest, Cup Holder & Carrying Case
- (1) 36" Center Dowel
- (1) 19" Footrest Dowel
- (2) 30" Armrest Dowels
- (1) Large "S" Hooks
- (1) Small "S" Hook

Make sure all of the above pieces are included prior to hanging your chair. If anything is missing, please contact Hammaka at info@kingspond.com.




Fig. 1




Fig. 2

CLEANING YOUR CHAIR

To wash, simply scrub with a soft brush using warm, soapy water and hang to dry. Do not use a washing machine, a tumble dryer, or any chemical bleaches/cleaners.

Step 1: HANGING THE HAMMOCK CHAIR

1. Hang the chair from the installed eye lag by tying the ropes to the large S-hook. Align the two rope ends and pass through the smaller part of the large S-Hook. Knot the rope as shown in the illustration. Pull knot tightly. Wrap any excess rope around the knot.

Step 2: INSTALLING DOWELS (see back side for dowel placement). (Dowel pocket holders will be snug - please fit dowel in firmly). **CAUTION: Pulling or putting pressure directly on the dowel in any way could result in injury and/or breaking of the dowels. Please DO NOT pull up on any of the dowels.**

1. Take large dowel (36") and place each side firmly into the black dowel pocket holders at the top of the chair.
2. Take the two medium dowels (30") and place each into the black dowel pockets above the right and left armrests.
3. Firmly press each dowel into the side black dowel pocket holders.

Step 3: HANGING THE FOOTREST

1. Take footrest rope and slide it through the small S-Hook.
2. Tie a secure knot.
3. Attach small S-Hook onto large S-Hook in ceiling joist.
4. The footrest may be adjusted up and down for comfort.
5. Take the small dowel (19") and fit firmly into each side of black dowel pocket holders.

Step 4: HANGING THE CUP HOLDER

1. Wrap cup holder strap around large dowel. Pull cup holder through opening and pull tight to secure cup holder.





Hammock Chair

Assembly Guide



CAUTION!

DO NOT JUMP OR BOUNCE IN THE HAMMAKA HAMMOCK CHAIR; DOING SO MAY CAUSE SERIOUS INJURY OR DEATH!

The Hammaka Hammock Chair's maximum weight capacity is 350 lbs. Do not exceed maximum weight capacity. Inspect hooks, and hardware before each use for rust or loosening that makes this product unsafe to use. If the functionality of the hardware has been compromised in any way do not use this product as doing so may cause serious injury or death. It may be necessary to tighten the hardware each time before using this product due to hot or cold weather conditions. Inspect the overall condition of this product before each use. Children should not use the Hammock Chair without adult supervision. Do not hang your chair more than eighteen inches above the ground. Make sure there are no sharp objects or harmful debris below where you hang your hammock.

WARRANTY AND CARE INSTRUCTIONS

One year warranty

For maximum life of this product Hammaka recommends putting the item indoors when you are located in extreme weather conditions. Check all connections to make sure they are secure each time before and periodically while using the product. Check that the hardware has not rusted. Hammaka recommends using a rust inhibitor available at your local hardware store to prolong the life of the hardware when leaving it outdoors.

Clean with mild soap and warm water, scrubbing when necessary.

Register your warranty online at www.hammaka.com.

Extend the use and life of your Hammock Chair by purchasing the All-weather Chair Cover from Hammaka.

