






IMPORTANT NOTICE:
HARDWARE PACKAGE IS ATTACHED ON THE
BOTTOM OF SEAT CUSHION.

(1)x1	(2)x1	(3)x1 (L)x1 (R)
		
Back Cushion	Seat Cushion	Left-Arm-L Right-Arm-R
(4)x1	(5)x1	(6)x 5
		
Gas Lift W/ Cover	Base	Caster
(7)x1	(8)x1	(9)x1
		
TU009-EXT	TU009	
(A)*2		M6*25 Arm Screws
(B)*4		M6*40 Arm Screws



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using.
This chair is only intended for sitting. Any other use will void the warranty.

