
X 2

Outdoor Patio Furniture Set

Model:WR720-US

NO.:YQ20251130



HELP CENTER

Have questions about this product? Contact us, and we'll assist you!

- Customer Support Email: support.us@soforoom.com

* Upon receiving your email, we'll respond within **48** working hours.

CENTRO DE AYUDA


¿Tienes preguntas sobre tu producto? Ponte en contacto con nosotros yte ayudaremos.

- Correo electrónico de atención al cliente：

  support.us@soforoom.com


*Al recibir tu correo electrónico, te responderemos en unplazo de **48** horas laborables.

WHAT DO YOU GET ?




Right Armchair

x 1




Single Chair

x 2




Left Armchair

x 1



Footstool

x 2



Coffee Table

x 1

ATTENTION:THESE 2 BOXES MAY ARRIVE AT DIFFERENT TIMES, PLEASE WAIT PATIENTLY.

FAQ

Q1: What should I do if the product I received is damaged or incorrect?

A1: If you've received a damaged, incorrect, or incomplete product, please reach out to our Customer Support Center at **support.us@soforoom.com**. Include your order number and photos.

Q2: What should I do if I encounter problems during installation?

A2: If you encounter any installation issues, please email to **support.us@soforoom.com**, attach a detailed description of the problem, we will provide you for professional technical support.

Q3: How do I apply a return?

A3: You can initiate a return within 30 days of purchase. Email us at **support.us@soforoom.com** with your order number and the reason for return. We'll guide you through the process.

Note:

- Please contact us before returning the product to avoid any complications.
- Ensure the product is returned in its original packaging with all accessories included.

PREGUNTAS FRECUENTES

P1: ¿Qué debo hacer si el producto que he recibido está dañado o es incorrecto?

R1: Si has recibido un producto dañado, incorrecto o incompleto, ponte en contacto con nuestro Centro de Atención al Cliente en **support.us@soforoom.com**. Incluye tu número de pedido y fotos que documenten el problema para que podamos ayudarte con la devolución o el cambio.

P2: ¿Qué debo hacer si encuentro problemas durante la instalación?


R2: Si tienes algún problema durante la instalación, por favor envía un correo electrónico a **support.us@soforoom.com**, adjuntando una descripción detallada del problema.
Te proporcionaremos soporte técnico profesional.

P3: ¿Cómo puedo solicitar una devolución?


R3: Puede iniciar una devolución en los 30 días siguientes a la compra. Envíenos un correo electrónico a **support.us@soforoom.com** con su número de pedido y el motivo de la devolución.
Te guiaremos a través del proceso.

Nota:

- Póngase en contacto con nosotros antes de devolver el producto para evitar complicaciones.
- Asegúrate de devolver el producto en su embalaje original y con todos los accesorios incluidos.




1 x 1




Right Handrail

2 x 1




Left Handrail

3 x 1




Right Backrest

4 x 1




Left Backrest

5 x 2



Backrest


6 x 4



Seat Board

7 x 2


Bottom With
Reinforcement Plate



Footrest Board


8 x 1

Sucker




Coffee Table Panel

9 x 1




Right Front
Baffle Plate

10 x 1




Left Front
Baffle Plate

11 x 2




Front Apron

12 x 6




Side Panel

13 x 12




Coffee Table
Side Panel

14 x 6




Seat Cushion

15 x 2




Armrest Cushion

16 x 4




Backrest Cushions

17 x 2




Throw Pillow

18 x 1



Glass Tabletop



Screw Bag A

A x 1



M6

B x 39+2




Screw with washer
M6*30 mm

C x 24+2



Screw with washer
M6*45 mm

D x 12



E x 6+1



Screw Bag B

A x 1



M6

B x 51+2




Screw with washer
M6*30 mm

C x 32+2




Screw with washer
M6*45 mm


D x 16



Detailed List





①	x 1
②	x 1
⑥	x 4
⑦	x 2
⑨	x 1
⑫	x 6
⑭	x 6
Screw Bag A	



③	x 1
④	x 1
⑤	x 2
⑧	x 1
⑩	x 1
⑪	x 2
⑬	x 12
⑮	x 2
⑯	x 4
⑰	x 2
⑱	x 1
Screw Bag B	

Right Armchair





A x 1



M6

B x 14+1




Screw with washer
M6*30 mm


C x 8+1




Screw with washer
M6*45 mm

D x 4






1 x 1




Right Handrail

3 x 1




Right Backrest

6 x 1




Seat Board

9 x 1




Right Front
Baffle Plate

12 x 1




Panel

14 x 1




Seat Cushion

15 x 1




Armrest Cushion

16 x 1




Backrest Cushions


17 x 1




Throw Pillow


1


⑥ x 1
⑨ x 1
⑫ x 1
A x 1
M6*30
B x 4



12
9
B
6
No screws are required here.


2


③ x 1
A x 1
M6*30
B x 4



B
12
3
No screws are required here.
9


3







4






5







Finish



Left Armchair





A x 1



M6

B x 14+1




Screw with washer
M6*30 mm


C x 8+1




Screw with washer
M6*45 mm

D x 4






2 x 1




Left Handrail

4 x 1




Left Backrest

6 x 1




Seat Board

10 x 1




Left Front
Baffle Plate

12 x 1




Side Panel

14 x 1




Seat Cushion

15 x 1




Armrest Cushion

16 x 1




Backrest Cushions


17 x 1




Throw Pillow


1


⑥ x 1
⑩ x 1
⑫ x 1
A x 1
M6*30
B x 4



B
12
10
6
No screws are required here.


2


④ x 1
A x 1
M6*30
B x 4



B
12
4
10
No screws are required here.


3







4






5







Finish




Single Chair





x 2



A x 1



M6

B x 13+1




Screw with washer
M6*30 mm

C x 8+1




Screw with washer
M6*45 mm

D x 4




E x 6+1






5 x 1




Backrest

6 x 1




Seat Board

11 x 1




Front Apron

12 x 2




Side Panel

14 x 1




Seat Cushion


16 x 1




Backrest Cushions


1


⑥ x 1
⑪ x 1
⑫ x 1
A x 1
M6*30
B x 4



12
B
11
6

2



③ x 1
A x 1
M6*30
B x 4



B
12
No screws are required here.
9
3

3



⑫ x 1
A x 1
M6*30
B x 5
B
12
9
3
No screws are required here.


4


A x 1
M6*45
C x 8
D x 4



C
C
D

5







Finish




6




Two sets of connecting clips are added between each two seats to ensure stability.



Coffee Table





A x 1



M6

B x 12+1




Screw with washer
M6*30 mm


C x 8+1




Screw with washer
M6*45 mm

D x 4






8 x 1




Coffee Table Panel

13 x 4




Coffee Table
Side Panel


18 x 1




Glass Tabletop


1







2






3







4






5







Finish



Footstool



x 2



A x 1



M6

B x 12+1




Screw with washer
M6*30 mm


C x 8+1




Screw with washer
M6*45 mm

D x 4






7 x 1




Footrest Board

13 x 4




Coffee Table
Side Panel


14 x 1




Seat Cushion


1







2






3







4





5





Finish

