

DINING CHAIR

ASSEMBLY INSTRUCTION



ASSEMBLY INSTRUCTIONS

Assembly Instructions


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial use.



ASSEMBLY TIME PER UNIT:

20 MINUTES


PARTS IDENTIFICATION

A.



2PCS

B.



CUSHION SEAT

2PCS

C.



LEFT LEG

2PCS

D.



RIGHT LEG

2PCS

E.






FRONT STRETCHER

2PCS


NOTE: QUANTITIES SHOWN ARE FOR TWO CHAIRS.

ASSEMBLY INSTRUCTION

Z	HARDWARE IDENTIFICATION		
1	ALLEN KEY-1/4"		1PC
2	ALLEN BOLT-Ø1/4"*16mm		12PCS
3	SCREW ØM5"*15mm		8PCS


ASSEMBLY INSTRUCTION

STEP 1



ASSEMBLY INSTRUCTION

STEP 2



STEP 3

