


Coffee Table

Assembly Instructions - Please keep for future reference

N721P525619



Dimensions

Diameter - 29.13 inch

Height - 13.78 inch

Important - Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

WARNING

In order to help prevent overturning – please follow these instructions



To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose



Components - Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases, more fittings may be supplied than required.


A  Ø10*45mm QTY: 1	B  QTY: 4	C  Ø6*12mm QTY: 4
ALLEN WRENCH	FOOT PAD	BOLT
D  QTY: 4	E  QTY: 4	
SPRING WASHER	FLAT WASHER	

COMPONENTS - KEY DIAGRAM



COMPONENTS - KEY DIAGRAM

1




Ø740x260mm

ROUND TABLE TOP

QTY: 1

2




Ø590x90mm

BASE

QTY: 1


ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2

The Base (2) is pre-packed inside the Top (1). Please remove the Base (2) and rotate it 180° before assembling it with the Top (1).





ASSEMBLY INSTRUCTIONS

STEP 3



B		4PCS
---	---	------

STEP 4



A		1PC
C		4PCS
D		4PCS
E		4PCS

ASSEMBLY INSTRUCTIONS

COMPLETED !

Please flip
carefully.

