

文件尺寸217*152mm*20吋塔罗亚吸顶风扇灯说明书双面铜版纸彩色装订--150本

TALOYA


Caged Ceiling Fan with Light

“What we can offer you is not only a light, but also an attitude towards life.”

Service Mailbox: info@taloya.com

Technical specifications

Caged Ceiling Fan Light
Model: TLY-MF1175-X-S
TLY-MF1175-X-H
TLY-MF1175-X-B
Input: AC100-240V 50/60Hz
Light:15W
Size: 20inch
Motor:13W



WARNING

Disconnect power prior to installation, inspection, or removal. Do not touch when light is on or when it is hot. If there is any problem with the fixture, turn power off and do not attempt to repair unless you are a qualified technician. Do not expose to water or rain. Ensure that after the fan is installed, its lowest point is no less than 2.1 meters from the ground.

Packing List

Motor assembly

Mounting bracket

Frame connection strap

Blades

Lamp

Remote-control

Lamp frames A

Lamp frames B

Screw Pack

Installation Guide

1

Remove the mounting bracket from the motor assembly.

2

First, remove the screws of the bracket connection pipe, and then use a wrench tool to secure the connecting pipe to the motor assembly.

3

Attach each blade to the motor using the provided screws. Note: The fan will not blow air downward if the blades are installed in reverse.

4

Connect the terminal wire on the motor assembly to the terminal wire on the lamp.

5

Slot the light fixture into the mounting plate until it clicks into place. (Tip: Place the fixture level on the bracket, hook one side first, then slide into place).

6

Connect lamp frames A and B using the provided connecting strap.

7

Use the connecting strap to assemble all lamp frame parts into a complete frame.

8

Fix the motor assembly and the combined lamp frame together using screws.

9

Fix the mounting bracket to the ceiling.

10

Connect the ceiling power wires: Black to live (L), White to neutral (N), Green to ground wire.

11

Mount the fan on the installation bracket attached to the ceiling.

12

Installation is complete.

Ceiling Fan Remote Control Manual

All Off

Fan off

Fan Forward

Light ON/OFF (Pairing Button)

Main Light Color Temp

Color Temperature-Fan Timer

Natural Wind

Buzzer Alert on/off

Wind Speed

Fan Reverse

Brightness +

Color Temperature + Brightness -

Kindly Reminders:

If the remote control unable to operate the fan, please follow the steps below to troubleshoot:
1. Check the remote control's battery for proper contact, correct placement and sufficient charge.
Low battery voltage can decrease the range and sensitivity of the remote. If the remote control is not used for an extended period, please remove the batteries.
2. Try re-pair the remote control with ceiling fan.

Pairing Method:

Turn on the power, press and hold the " " button within the first 5 seconds of the light turning on. When you hear the "beep" sound or see the light flashing, the pairing is successful. If you need to pair again, wait for 30 seconds after turning off the power and repeat the above steps.

Input voltage: AC100V-240V 50/60Hz

Power by 2xAAA batteries (not included)

AFTER-SALES SERVICE SUPPORT

Thank you so much for choosing Taloya as your preferred brand for your recent purchase. We hope the product has met or exceeded your expectations. We appreciate your trust in us and are thrilled to have you as part of our valued customer community.

We hope you are enjoying your purchase and are pleased with the product's performance. However, we understand that sometimes issues can arise during usage. In such cases, we are here to help. Please do not hesitate to contact us if you encounter any problems. Our team will go above and beyond to assist you and find a solution promptly.

Service Mailbox Channel: info@taloya.com

TALOYA

“What we can offer you is not only a light, but also an attitude towards life.”

info@taloya.com
www.taloya.com