


INSTRUCTION MANUAL

Thank you for your support.
Follow us for more updates!



**We stand behind we sell. If you are not satisfied with your purchase,
you can return it for a replacement or refund.**

For any further question don't hesitate to contact us. Email:



youfurniture@163.com

SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT

CAM-LOCK




**WHEN FITTING CAMLOCK
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING QUICKFIT
TURN CLOCKWISE UNTIL SECURE**














Quickfit head needs to be in centre

QUICKFIT


**Tighten until shoulder is flush
with panel. DO not overtighten
or undertighten (see example
below)**








PART LIST


A  20+2PCS	B  20+2PCS	C  ø6x30 16+1PCS
D  M4x35 6+1PCS	E  M3x10 8+1PCS	F  1SET
G  4+1PCS	H  M3x16 4+1PCS	CL  1PCS
CR  1PCS	DL  1PCS	DR  1PCS



BOARD IDENTIFICATION






Ax10	Ex4	CLx1	CRx1
			

Ax6





Bx2	Cx2
	











Bx5

Cx4







Bx5	Cx4
	











Gx4
Hx4



Ax4	Dx4



Bx4
Ex4
DLx1
DRx1
Fx1



CONTACT US !

Do Not return this product

Contact our friendly customer service team first for help.

①



youfurniture@163.com

②



Amazon Message

If you have any questions, please leave the order No. and related picture information, we will reply you within 24 hours, and solve the problem as soon as possible.