


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Allen Wrench
(Included)



2 - People
Recommended

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

- Are you missing anything?**
Double-check all parts, hardware and accessories listed on Page 6 are accounted for.
- Check out our Quick Tips!**
We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
- Should we send any replacements?**
Are there any irregularities or flaws in the parts? We can send replacements!
- Prep Time!**
Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.



Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS

#1 1pc





Table Top

#2 2pcs




Leg-R/L

#3 2pcs




Cover

#4 1pc



Center stretcher

#5 2pcs



Center stretcher


HARDWARE

#A 2pcs



Bolt
Ø1/4"x 2-1/2"

#B 8pcs



Bolt
Ø5/16"x1-3/4"

#C 12pcs



Bolt
Ø5/16"x1-1/2"

#D 22pcs



Lock Washer
Ø5/16"

#E 20pcs




Flat Washer
Ø5/16"

#F 1pc



Allen Wrench M4




ASSEMBLY INSTRUCTIONS

1

- Part #2 x 2pcs
- Part #4 x 1pc
- Hardware #A x 2pcs
- Hardware #D x 2pcs


Prepare 2 bolts assembly by inserting washer (#D) onto bolts (#A). Align center support (#4) to the holes of the legs (#2R/L), then secure with bolts (#A).



2

- Part #3 x 2pcs
- Part #5 x 2pcs
- Hardware #B x 8pcs
- Hardware #D x 8pcs
- Hardware #E x 8pcs

Attach cover (#3) to the center holes of the legs (#2L/R).




Prepare 8 bolts assembly by inserting lock washer (#D), then flat washer (#E) onto bolts (#B). Align cover panel (#5) to the holes of the legs (#2R/L), then secure with bolts (#B).

ASSEMBLY INSTRUCTIONS


3

Prepare 12 bolts assembly by inserting lock washer (#D), then flat washer (#E) onto bolts (#C). Align cover panel (#5) to the holes of the table top (#1). Secure with bolts (#C).

- Part #1 x 1pc
- Hardware #C x 12pcs
- Hardware #D x 12pcs
- Hardware #E x 12pcs



4



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.