




Thank you for your purchase!



2 Drawer Nightstand



ASSEMBLY INSTRUCTIONS

Before You Begin: (Phillips screwdriver required, not included)

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Warning:


CHOKING HAZARD - Small Parts. Adult Assembly Required.

DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE


Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.

Parts List




A Top Panel x 1



B Bottom Panel x 1




C Support Bar x 2




D Back Panel x 1




E Legs x 4




F Left Side Panel x 1




G Right Side Panel x 1




H Drawer Front x 2




J Drawer Back x 2



K Left Drawer Side x 2



L Right Drawer Side x 2



M Drawer Bottom x 2

Hardware List



1 M6 x 15mm JCB x 16



2 M6 x 60mm JCB x 8




3 M4 x 25mm Wood Screw x 16



4 M4 x 20mm Wood Screw x 8



5 M4 x 16mm Wood Screw x 6



6 CSK Cap Wood Screw (M6 x 60mm) x 4



7 Spring Washer x 8



8 Flat Washer x 8




9 'L' Bracket (5005-3) x 8




10 Allen Key x 1


- 1** Attach Left and Right Drawer Sides (K & L) to the Drawer Fronts (H).




- 2** Slide the Drawer Bottoms (M) into the grooves on the Drawer Sides (K & L) and the Drawer Fronts (H).




- 3** Attach the Drawer Backs (J) to the Drawer Sides (K & L).




4 Attach the 'L' Brackets to the Side Panels (F & G).




5 Attach the Side Panel (F & G) to the Top Panel (A). Tighten all screws.




6 Attach the Support Bars (C) to the Side Panels (F & G).




7 Slide the Back Panel (D) into the grooves Side Panels (F & G).




8 Attach the Bottom Panel (B) to the Bottom of the Side Panels (F & G).



9 Use screws to tighten the Back Panel (D) to the back of the frame.




10 Attach the Legs (E) to Bottom Panel (B).




11 Adjust the Drawer Fronts (H).

* Loosen screws on the inside of the Drawer Fronts to align



- 12** Once the Drawer Fronts are aligned, secure with wood screws.



Quality and Safety Guidelines:

- Please follow the static and dynamic weight capacity limits provided on this item. If you are unsure of the weight capacities for this product, email us.
- Please use this item on a stable, level surface only. All legs, feet should contact the flooring surface when in use. Do not use this item if any instability is detected.
- Never push, pull or drag this product.
- Adult supervision required.
- For maintenance instructions and replacement parts, please email us.
- This item is intended to be used as a table only. Do not climb, stand or sit on this item. Do not use this item as a TV stand. Do not place heavy objects on top of this product.
- The item is intended to be used indoors.
- Please inspect this product regularly to make sure there are no damaged or worn parts. Also inspect to make sure all hardware is tightened correctly and securely. For inspection instructions, please email us.
- If any parts are damaged or worn, please stop using the product. Repair this product with manufacturer supplied parts only.
- For product longevity, product safety and product integrity, protect from wet and humid weather or other wet, humid or moist conditions and store indoors in a dry location. For additional storage and usage instructions, please email us.