


ASSEMBLY INSTRUCTIONS



Colorado











Congratulations on selecting a Colorado slate pool table - part of the Fairfield Collection by Playcraft. Please contact us via email at support@playcraft.com should you require any assistance.

Please carefully read all safety instructions and directions before proceeding

- 1) Your table is designed for use indoors in a climate controlled environment only. Damage can occur if the table is exposed to water, dampness, high humidity, freezing temperatures, etc.
- 2) Professional assembly is strongly recommended. This assembly manual is intended to guide an experienced slate pool table installer with the assembly process of this specific cabinet. It does not guide on setting the slate or attaching the billiard cloth for which the process is the same regardless of the cabinet type.
- 2) The pool table cabinet and slate are extremely heavy. Two or more people are required for assembly.
- 3) The table must be assembled in the final location where the table will be played. Attempting to move the table once assembled could result in damage to the table or serious injury.
- 5) Only use the table for its intended purpose.
- 6) Damaged or worn parts may be dangerous for users and the integrity of the table. Replace worn or damaged components immediately and do not use the table until any issues have been resolved. For best results, use only spare parts supplied by Playcraft.
- 7) Unauthorized repairs or altering the table's design or functions may be dangerous and will void the warranty.
- 8) Check all screws, bolts, etc. on a regular basis to ensure that they are in good working condition and have not loosened over time.
- 9) Over time, pool tables may require releveling. This is considered normal maintenance as required with owning a slate pool table


COMPONENT LIST

NO.	IMAGE	DESCRIPTION	SPECIFICATION	QTY	UNIT
H1		TABLE LEG	1100*745*200	2	PCS
		ASSEMBLY POSITION	FRAME		
H2		SUPPORT BEAM	1696*150*80	1	PCS
		ASSEMBLY POSITION	FRAME		
H3		FRAME	2052*889*57	1	PCS
		ASSEMBLY POSITION	GRADE A BEAM		
H4		WOODEN BLOCK	125*92*80	12	PCS
		ASSEMBLY POSITION	GRADE A BEAM		
H5		SHORT BEAM	1173*180*40	2	PCS
		ASSEMBLY POSITION	GRADE A BEAM		
H6		SHORT BEAM	1936*180*40	2	PCS
		ASSEMBLY POSITION	GRADE A BEAM		
H7			893*120*40	2	PCS
		ASSEMBLY POSITION	GRADE A BEAM		
H8		SIDE SLATE	805*1295*25	1	
		ASSEMBLY POSITION	TOP RAIL		
H9		MIDDLE SLATE	805*1295*25	1	PCS
		ASSEMBLY POSITION	TOP RAIL		
H10		SIDE SLATE	805*1295*25	1	
			TOP RAIL		
H11		CLOTH		1	
			TOP RAIL		
H12		1# RAIL	1064*145*163	2	PCS
		ASSEMBLY POSITION	TOP RAIL		
H13		2# RAIL	1026*145*163	2	PCS
		ASSEMBLY POSITION	TOP RAIL		
H14		3# RAIL	1026*145*163	2	PCS
		ASSEMBLY POSITION	TOP RAIL		
H15		MATEL FRAME	140*80*10	2	PCS
		ASSEMBLY POSITION	FRAME		


HARDWARE LIST

NO.	IMAGE	DESCRIPTION	SPECIFICATION	QTY	UNIT
A		HEXAGON BOLT	ø10*110	8	PCS
		4PCS FOR CONNECTING THE LEG AND BOTTOM SUPPORT BEAM , 4PCS FOR LEG AND CROSS BEAM			ASSEMBLY POSITION
B		FLAT WASHER	M10*30*2	8	PCS
		4PCS FOR CONNECTING THE LEG AND BOTTOM SUPPORT BEAM , 4PCS FOR LEG AND CROSS BEAM			ASSEMBLY POSITION
C		FLAT HEAD SCREW	4.2*60	100	PCS
		USED TO FIX THE GRADE A BEAM			PCS
D		HEXAGON BOLT	ø12*180	4	PCS
		USED TO FIX THE CROSS BEAM			ASSEMBLY POSITION
E		FLAT WASHER	M12*30*2	4	PCS
		USED TO FIX THE CROSS BEAM			ASSEMBLY POSITION
F		ACRON NUT	M12	4	PCS
		USED TO FIX THE CROSS BEAM			ASSEMBLY POSITION
G		HEXAGON BOLT	ø10*140	4	PCS
		USED TO FIX THE TABLE LEGS AND GRADE A BEAM			ASSEMBLY POSITION
H		SLATE LEVELLER	ø10*50	16	PCS
		USED TO ADJUST AND LEVEL THE SLATE			ASSEMBLY POSITION
I		FLAT HEAD SCREW	6*60	12	PCS
		USED TO FIX THE AND TABLE FRAME			ASSEMBLY POSITION
J		HEXAGON BOLT	ø8*35	12	PCS
		USED TO FIX THE LEATHER POCKET(PACKED IN THE BOX WITH LEATHER POCKET)			ASSEMBLY POSITION
K		FLAT WASHER	M8	12	PCS
		USED TO FIX THE LEATHER POCKET(PACKED IN THE BOX WITH LEATHER POCKET)			ASSEMBLY POSITION
L		SIDE POCKET		4	PCS
					ASSEMBLY POSITION
M		MIDDLE POCKET		2	PCS
					ASSEMBLY POSITION
O		HEXAGON BOLT	ø10*60	18	PCS
		USED TO FIX THE TOP RAILS AND SLATE			ASSEMBLY POSITION
N		DOME WASHER	ø10*60	18	PCS
		USED TO FIX THE TOP RAILS AND SLATE			ASSEMBLY POSITION


Step 1




Step 2




Step 3




Step 4




Step 5




Step 6






Step 7





Step 8



Step 9



Step 10





Customer Service

For questions on assembly or for missing or damaged parts, please contact us via email at support@playcraft.com. Please visit our website at www.playcraft.com to see more industry leading Playcraft and Playcraft Sport game tables.

Thank you for choosing Playcraft!

Global Merchants, Inc.
12 Lunar Drive
Woodbridge, CT 06525