

---

## Care and Cleaning

---


Remove cartridge and clean valve body in household vinegar to remove corrosive mineral build up. Rinse under running hot water to ensure valve is free of foreign debris.

---

## Trouble Shooting Chart

---

Problem	Cause	Solution
Water flow is less than normal.	Screen in cartridge is dirty or clogged.	1) Remove cartridge and clean under running water. 2) Remove cartridge and clean in household vinegar or replace by ordering cartridge replacement kit.
Water continues to run colder than original temperature setting.	Check valve is not completely sealed allowing cold water to mix with hot.	Remove screen/check valve and clean under running water.
Valve is leaking around the cap retaining nut area.	Water leaking from o-ring seal.	Replace cartridge by ordering cartridge replacement kit.
Tempered hot water temperature is not hot enough.	Hot water supply into valve is not 10°F (5.55°C) above desired set point temperature. Temperature setting it to low.	Increase hot water supply temperature into valve. Reset temperature according to "Setting valve temperature" instructions.

 **WARNING:** This product can expose you to chemicals including lead, which is known to the state of California to cause cancer, birth defects, or other reproductive harm. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).