

Rechargeable Cordless Ceramic Lamp

USER MANUAL



PREMIUM CERAMIC



SOFT LIGHT



RECHARGEABLE DESIGN



Product Size & Function Guide

11.8 inch

18.5 inch

1 Short Press
Tap to turn ON/OFF

2 Long Press
Stepless dimming adjust brightness

3 USB Charging Port
Rechargeable & cordless

4 Charging Indicator
Blue light on while charging; indicator off when fully charged.

Built-in rechargeable battery for cordless use.

Please fully charge before first use.

Product Specifications & Battery Guide

Product Specifications

Battery Capacity	5000mAh (3.7V)
Battery Type	Rechargeable Lithium Battery
Charging Port	USB Type-C
Input Voltage	DC 5V = 2A
Dimming	Stepless Dimming
Material	Ceramic + Fabric

Approx. Runtime

*Actual runtime may vary depending on usage and environment.

High Brightness	6-8 hours
Medium Brightness	10-14 hours
Low Brightness	18-24+ hours

Charging Guide

- Charging Time: 3-5 hours
- Use 5V/2A Adapter for Faster Charging
- Fully charge before first use


Important Notes

- Battery life varies depending on brightness level.
- It is normal for the lamp to feel slightly warm during use or charging.
- This lamp is designed for ambient lighting, not continuous high-intensity lighting.

Removable Fabric Lampshade Installation


Installation Guide

1 Unroll the fabric shade




2 Wrap around the frame

Ensure that the frame and the clasps on the shade are secured in place.



3 Press and secure



Adjust the shape until round and even.




Note:

The lampshade is packed flat for safe shipping. Slight creases are normal and will relax after installation.




1 Twist to Remove the Socket Ring

Remove the socket ring by turning counterclockwise.




2 Place the Lampshade

Place the lampshade upside down with the metal ring facing down and secure it on the lamp base.



3 Tighten the Socket Ring

Reinstall the socket ring by turning clockwise to secure the lampshade.



4 Install the Bulb

Screw the bulb (E26 base) into the socket.

Care, Safety & Helpful Tips

1 Important Precautions



For indoor dry locations only.



Place on a stable, flat surface.



Keep away from water, fire, and high heat.



Do not cover the lampshade while in use.



Do not disassemble or modify the lamp.

2 Cleaning & Maintenance



Turn off the lamp before cleaning.



Wipe with a soft, dry cloth only.



Do not use alcohol, corrosive cleaners, or water spray.



Handle the base and fabric shade gently to avoid damage.

3 Helpful Tips Before Return



Slight variations in ice-crack pattern are normal.



The lampshade color may look slightly different under different room lighting.



Please keep the touch area clean and dry for better response.



If the product arrives with any issue, please contact customer support for assistance.



Indoor Use



Soft Cloth Only



Handle with Care