

Hair Dryer

FEATURES AND FUNCTIONS:

- ❖ The machine introduces temperature-control system, it's reliable and wear well.
- ❖ The heat unit is made with stainless steel material, which is very timeproof.
- ❖ The machine has hot perm, hair-drying, hair-treatment and spot-caring functions.
- ❖ The temperature can be adjusted from room temperature to 75°C

INSTALLING STEPS:

- ❖ Open the carton, take out the two feet base, feet connection and assemble them.
- ❖ Connect the adjustable tube to the supporting column. Slide on the black plastic height adjusting knob and lock it in place.
- ❖ Connect the supporting column into the middle of five plastic feet, install the screw with spacer on the bottom of the plastic feet and tighten the screw.
- ❖ Install the screw with spacer above the support frame, then insert to adjustable tube.
- ❖ Install the machine.

OPERATIONS:

- ❖ Turn power, turn the time switch rightwards to set the suitable time and turn the temperature aduster to set the suitable temperature.
- ❖ To heat quickly, the temperature adjuster should be turned the furthest, when the temperature is suitable, it can be adjusted back to a suitable sit us .

ATTENTIONS:

- ❖ Sure the mainframe fittings tightening before the machine is fitted together.
- ❖ The flexing tube must be closed upon when it is fixed and adjusted just in case of springing.
- ❖ Don't use the machine if it is unnormal or the power cable is aged .The machine must be serviced by a professional accendant or serviced in the specified site.
- ❖ Turn the temperature knob to "COOL" position for at least one minute before turn off the "POWER" switch (red switch in the middle)

Instruction Manual

