





Installation manual



A1				A2			
*6*38mm		+15*11mm					
A	28 PCS	B	9 PCS	C	26 PCS	D	10 PCS
E		4 PCS		F		4 PCS	
		+12*10mm		G		10 PCS	
		6*30mm		H		2 PCS	
				I		2 PCS	
		96mm		J		1 PCS	
		18mm		K		4 PCS	
				L		1 PCS	
		18mm		M		4 PCS	
				N		1 PCS	
				P		8 PCS	
		6*40mm					




1



			
K	4 PCS	P	8 PCS


3



			
A1	6 PCS	A2	1 PCS




2




			
C	4 PCS	C	4 PCS


4




			
A1	6 PCS	A2	1 PCS


5



				
C 4 PCS	D 4 PCS	E 4 PCS	F 4 PCS	H 1 PCS

250mm	J2 2 PCS
	


7



		
A 6 PCS	B 2 PCS	




6






	
A 2 PCS	


8




		
A 6 PCS	B 2 PCS	





 A1 #6*38mm		 A2 #15*11mm		 B #8*40mm	
A	4	PCS	B	4	PCS



 D ST4*35mm	
D	6 PCS




 C ST3.5*14mm		 J1 250mm		 J2 18mm		 M		 N	
C	6 PCS	J1	2 PCS	L	1 PCS	M	4 PCS	N	1 PCS





6*30mm

G

10 PCS





		ST3,5*14mm					
C	12 PCS	H	1 PCS	I	1 PCS	I	2 PCS