


Dress Up Storage




WARNING

CHOKINGHAZARD-small parts, Not for children under 3 yrs, The product is to be assembled by an adult.

WARNING


Prior to assembly this package contains sharp edges and sharp points.Keep away from children until assembled.

Exploded Drawing




Product Parts


A




B




C




D



E




F




3 pcs


G



H



I




J



K




L




2 pcs


M




N




O




P



Q



R



2 pcs

3 pcs

2 pcs

2 pcs

Hardware


1



Ø4*28mm

50 pcs

2



Ø5*30mm

2 pcs

3



4 sets

4



1 pc


5



1 set


Step 1

1  12 pcs
 $\varnothing 4 \times 28 \text{mm}$



Step 2


1  18 pcs
 $\varnothing 4 \times 28 \text{mm}$



Step 3


1  2 pcs
 $\varnothing 4 \times 28 \text{mm}$

2  2 pcs
 $\varnothing 5 \times 30 \text{mm}$




Step 4

1  3 pcs
 $\varnothing 4 \times 28 \text{mm}$




Step 5




Step 6

- 1  4 pcs
Ø4*28mm




Step 7

- 1  2 pcs
Ø4*28mm




Step 8

- 3  2 sets 4  1 pc




Step 9




Step 10

- 1  6 pcs
 $\varnothing 4 \times 28 \text{mm}$




Step 11

- 3  2 sets 4  1 pc




Step 12


- 1  3 pcs
 $\varnothing 4 \times 28 \text{mm}$




Step 13



Step 14



Step 15



WALL MOUNTING ASSEMBLY

For added safety and stability, it is recommended that the wall mounting hardware be installed. For safe mounting, it is essential to use wall anchors appropriate to your wall type (i.e. plaster, drywall, concrete, etc.). Mount to wood studs whenever possible.

Use a 1/4" (6.5mm) drill bit to pilot the hole. If mounting to plaster, wood panels, brick or other drywall please consult a qualified professional.

Please make sure you use the right hardware for your wall type for your safety.

WARNING:
Do not install on a wall where items can fall off and injure a child.

WARNING:
CHOKING HAZARD, Unassembled parts may be choking hazard to children 3 years and younger.

CAUTION:
Adult assembly required.
Hardware contains small screws with sharp points.
Keep unassembled parts out of reach of small children.

Hardware

A. Screw x 1
M4x25mm



B. Small Washer x 2
Φ10XΦ5X1mm




C. Plastic Anchor x 1



D. Plastic Anchor x 1



The following tools (not included) are required for assembly:



Electric Drill

E. Wood Screw x 1
Φ4X32mm



F. Nut x1



G. Large washer x1
Φ16XΦ6X1mm



Wrench x1



1/4" (6.5mm) Drill Bit




Phillips® Screwdriver

Step 1

Attach Plastic strip to back of product.

Hole predrilled in product backboard #F




Step 2

Use 1/4" (6.5mm) drill bit to drill hole in wall

Do not drill an oversized hole or the wall anchor will not hold tightly into the wall.

Tap wall anchor into hole.

Secure product to wall with screw "E" through Plastic strap and into wall anchor.



Warning:

Serious or fatal injuries can occur from furniture tip-over. To help prevent furniture tip-over:

Use provided mounting hardware to secure furniture to the wall.

This may reduce but not eliminate the risk of furniture tip-over.

Do not allow children to climb on furniture.

Keep remote controls, toys, and other items that might attract children off of this product.

Unless specifically designed to accommodate, do not set televisions or other heavy objects on top of this product.