

Safety Information

1. Caution!If you feel uncomfortable tingling heat or if the skin turns red,there is a risk of burns.Turn off the device immediately and stop use immediatel. Read the safety information carefully before first use.
2. Do not allow water to collect or pool on the chair. Chair should be completely dry before attaching battery and powering on.
3. Heating elements should not be allowed touch bare skin.
4. Shut off power immediately if discomfort occurs.
5. Do not allow the wires in the product to be pinched.
6. Discontinue use of this product if it stops working correctly or heats inconsistently.
7. Do not use pins or around this jacket as they can cause damage to wiring.
8. Remove the battery pack from the battery pocket before washing.Spot clean only.
9. Do not dry clean.Do not use dry-cleaing fluid on this item.Do not bleach. Cleaning solvents may have a detrimental effect on the insulation of the heating elements.
10. Do not iron.
11. Do not use if you have impaired temperature sensitivity.Consult with your doctor before use.
12. Keep the product out of the reach of children,as it contains small parts which could be easily swallowed.
14. This item should be serviced by a qualified repair person using only identical replacement parts.
13. Always turn off the device and disconnect the batteries when it is not in use.



USER INSTRUCTION

Heated Camping Chair



How to heat



- 01** Locate the battery pocket found on the right side of the chair. attach the battery (Battery not included in our package, you need to buy somewhere) to the cable inside the pocket, place the battery in the pocket, then close the zipper on the pocket



- 02** Press and hold the button for 2s until the red light turns on (red light is High Heat)



- 03** Click the button to switch the temperature level. Blue light is medium heat, green light is low heat. When not in use, long press 2s to turn off.



- 04** The chair has two heating zones with two USB cables, one for heating the back and one for heating the seat.

How to Store and Carry



- 01** Hold the chair with both legs and press inward.



- 02** Fasten the Velcro



- 03** You can carry it anywhere on your back

NOTE:

1: Make sure the power bank supply(Battery not included) is in working condition before use

2: The chair has two heating zones with two USB cables, one for heating the back and the other for the bottom.

3: If it is not heated, you can check the following situations

- ①. If the breathing light is not on, it must not be working or heating; if the breathing light is on, it is usually heating.
- ②. For outdoor use in winter, the temperature is low, and the hand feels little heat, so you need to sit on it to experience
- ③. One power bank can only correspond to one heating area. If you want to heat the back and bottom at the same time, you need to connect 2 chargers.
- ④. If only one area (back or bottom) is heated. check whether only one USB cable is connected. If the two parts are heated together, two USB cables need to be connected together.

4: Rated current and voltage of each heating area: 5V2A, power 10W; if you use a 5V2A, 10W power bank can only heat one area of the back or seat, and cannot heat it at the same time, two power banks need to be connected to the USB cable respectively; If you want to use a mobile power supply to heat your back and seat at the same time, the mobile power supply needs to meet:

- ①. The power is greater than 20W.
- ②. Two USB cables can be connected to the portable charger.