



ASSEMBLY INSTRUCTIONS



+ Do Not Use Power Tools



+ Suggested Adults



NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

- part # - Corner base
- part # - Corner cushion
- part # - Armless chair base
- part # - Armless chair cushion
- part # - Chrome leg
- part # - Gold leg

Do not assemble if any of the following Hardware parts are missing:

- part # - Allen wrench
- part # - Bolt M8"*35mm
- part # - Washer M8*16mm
- part # - Connect metal plate


2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+ Parts Included



- ① Corner base
1pc

- ② Corner cushion
1pc




- ③ Armless chair base
1pc

- ④ Armless chair cushion
1pc



- ⑤ Chrome leg
8 pcs

- ⑥ Gold leg
8 pcs



+ Hardware Included


- A** Allen wrench
1 pc

- B** Bolt M8"*35mm
24pcs



- C** Washer M8*16mm
24 pcs

- D** Connect metal plate
100*75*18mm
2 pcs



ASSEMBLY INSTRUCTIONS

