

ASSEMBLY INSTRUCTIONS

ASSEMBLY

30 MINUTES

1-Person

REQUIREMENTS


Assembly Time
Per Stool (Approximate)

Assembly

Thank you for purchasing our product!

Please refer and use this assembly instruction to assemble the product. Contact our customer service department in case there are any missing or damage parts or hardware. Replacement parts are normally shipped within 2 or 3 days.

We appreciate your business!



ASSEMBLY PREPARATION

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List, and ensure parts and hardware are correct before assembly.
Contact customer service for missing parts.
3. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent scratch and damage to parts.

SAFETY PRECAUTION:

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.

TIPS FOR ASSEMBLY:

1. Allow ample room for assembly and in close proximity to where product will be placed.
2. Assemble the product on a surface that does not scratch or damage the exterior gloss and finish of the furniture.
3. Identify all of the parts, hardware and quantities required for each step.
4. During assembly, do not over-tighten any fittings as this may cause damage.
5. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
6. Always place the product on a flat .level surface.
7. Do not sit or stand on the partially assembled product; only use the product for which it is intended.

CARE AND MAINTENANCE


- Use a slightly damp cloth to clean the product. Do not use bleach or abrasive cleaning material.
- Check all the fittings periodically and re-tighten as necessary. Do not use the product if any of the parts is damaged or broken.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or delaminate.
- Do not place hot items (e.g. hot drinks) directly onto the wood surface.
- Do not drag and/or pull the furniture.

This product is for indoor and household use only - not for commercial use.

ASSEMBLY INSTRUCTIONS


A		CHAIR BACK	2PCS	E		WOOD SEAT	2PCS
B		LEG FRAME	4PCS	F	 1/4 X 12MM	BOLT	12PCS
				G	 1/4*35MM	BOLT	8PCS
D		LEG STRETCHER	2PCS	H		ALLEN WRENCH	1PC

STEP 1



- Place Wood Seat (E) bottom-side up on soft material to prevent scratch and damage.
- Use Screw (F) to fasten Leg Frame (B) to (E). Use Allen Key (H) to drive (F). Do not tighten (F) completely until both screws are in place on each leg frame.

STEP 2



- Fit Leg Stretcher (D) across Leg Frame as shown.
- Use Screw (F) to fasten (D) to Leg Frames. Use Allen Key (H) to drive (F). Do not tighten (F) completely until both screws are in place.
- Set Seat & Leg Frame assembly right-side up.

STEP 3

- Position Chair Back (A) over the rear edge of Wood Seat (E) as shown to align the screw holes on the bottom of (A) to the screw holes on (E).
- Insert Screw (G) from the bottom of (E) to fasten (A) to (E). Use Allen Key (H) to drive (G). Do not tighten (G) completely until all of the Screws (G) are in place. Do not over-tighten.

The assembly of the chair is complete.

