

Assembly Instructions

Caution: You must read this before you proceed


Care & Maintenance

- | | |
|---|---|
| ⊘  | <ul style="list-style-type: none">• Not for commercial use. For residential use only. |
| ✓  | <ul style="list-style-type: none">• Furniture may scratch floors. We recommend using furniture pads to protect your floors. |
| ⊘  | <ul style="list-style-type: none">• Do not put hot items directly on furniture surface. |
| ⊘  | <ul style="list-style-type: none">• Do not clean furniture with harsh cleansers or polish. |
| ⊘  | <ul style="list-style-type: none">• Do not place furniture under direct sunlight. |
| ⊘  | <ul style="list-style-type: none">• Do not place furniture near heating or cooling vents. |
| ⊘  | <ul style="list-style-type: none">• Do not write on furniture without a padded barrier to protect the surface. |
| ⊘  | <ul style="list-style-type: none">• Do not place furniture outside . For indoor use only. |
| ⊘  | <ul style="list-style-type: none">• Stains may be removed with mild soap solution and damp cloth. |
| ⊘  | <ul style="list-style-type: none">• Children should not climb or jump on the furniture. |
| ✓  | <ul style="list-style-type: none">• Dust and pick-up spills using a clean, non-colored, lint-free cloth. |

Please look in the magic tape pouch for hardware packs and legs.







Sets often ship in multiple boxes and may arrive a day or two apart.

RECLINER
N763P449960



Part List

N763P449960

Label	Picture	Description	QTY
A		Backrest	1
B		Left Wing	1
C		Right Wing	1
D		Chair Base	1
E		Front Leg	2
F		Hind Leg	2


Hardware

N763P449960

Label	Picture	Description	QTY
①		Plastic Washer	4


ASSEMBLY STEPS

OVERVIEW




ASSEMBLY STEPS

STEP1




1.1 Take the Backrest (A) out from the Chair Base (D)

STEP2



2.1 Place the Chair Base (D) facedown on the clean, non-marring surface Take out the non-woven bags. Remove the non-woven bags to take out the Left Wing (B), the Right Wing (C), Front Leg (E) and Hind Leg (F)

STEP3




3.1 Install one of the Front Legs(E) and a Hind Leg (F) into the bottom of the Recliner by placing one Gasket(①) on the threaded stem. Then insert the threaded stem into the mounting positions at the corner of the Recliner. Tighten by turning the Legs clockwise. Do not over tighten.

Repeat the same process to install the remaining Legs. Take notice of the shape of the Legs and ensure they are in the correct positions.

Note: The use of Gaskets are OPTIONAL and are especially useful to help alleviate slight wobbleness. Some Legs may need more than one gasket whilst some Legs may not need any.

STEP4




With assistance from your adult partner, hold up the Backrest(A).

While standing behind the Recliner, insert the small metal arms on the sides of the Backrest(A) into the prefabricated slide lock gadgets on the Chair Base (D) as shown above.

Firmly but gently, push the Backrest(A) downwards until the Backrest(A) is fully slotted and locked into position.


STEP5



5.1 Align the mounting brackets of the Left Wing(B) with the one on left side of the Backrest(A).
Then slide the mounting brackets together until they lock into position as shown above.

5.1 Align the mounting brackets of the Right Wing(C) with the one on left side of the Backrest(A).
Then slide the mounting brackets together until they lock into position as shown above.


STEP6



6.1 Smooth down the fabric flap on the Backrest(A).
Run your hands down both sides of the flap, from top to bottom, allowing the Magic Tape to adhere to the flap under the seat of the Recliner.

STEP 7

COMPLETED



Make sure all parts are connected and securely locked into position.
Your recliner is ready for use.
This recliner can only be used on a flat, level surface.