


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Hammer

(Not Included)



Philips Screwdriver

(Not Included)



**2 - People
Recommended**

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!


☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.




Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Save the instructions and store
any supplied tools for later
maintenance.

Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS

Note :


Every cam lock bolt must have a cam lock connector in order to fasten the parts together.




cam bolt



cam lock




screwdriver




1

Screw the cam bolt into panel.




2

Insert the cam bolt into the bolt hole of joint panel.



3


Align the cam lock with its side opening (or arrow) pointing to cam bolt.




4

Turn the cam lock clockwise gently until it will not turn any more.

COFFEE TABLE




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

A1PC




B1PC




C1PC




D1PC




E1PC



F1PC



G1PC



H1PC



I1PC



J1PC



K1PC



L2PCS



HARDWARE

① 19PCS



② 19PCS



③ 19PCS



④ 2PCS



⑤ 1PC



⑥ 1PC



⑦ 12PCS



⑧ 4PCS



⑨ 4PCS



⑩ 2PCS



ACCESSORIES

A1 5PCS



A2 20PCS



A3 1PC



A4 12PCS



A5 1PC



A6 1PC



A7 1PC



A8 1PC



A9 3PCS



A10 6PCS




A11 5PCS




GET READY

Please group boards as below.

E1PC




I1PC



J1PC



D1PC




L2PCS




C1PC



F1PC




G1PC




K1PC



H1PC



A1PC



B1PC



Body









ASSEMBLY INSTRUCTIONS

1

Hardware ① x 19PCS

Hardware ③ x 19PCS





Accessory A3 x 1PC



ASSEMBLY INSTRUCTIONS


2

Part **E** x1PC
Part **I** x1PC
Part **J** x1PC
Hardware **2** x 1PC



3





Part **D** x1PC
Part **L** x2PCS
Hardware **4** x 2PCS
Hardware **8** x 4PCS
Accessory **A5** x 1PC



ASSEMBLY INSTRUCTIONS

4


Part **C** x1PC
 Part **G** x1PC
 Hardware **2** x 7PCS
 Accessory **A4** x 4PCS



Front
 Top

5

Part **K** x1PC







Front
 Top

ASSEMBLY INSTRUCTIONS

6

Part **F** x1PC
 Hardware **2** x 7PCS
 Accessory **A4** x 4PCS





X 4

Front
 Top

7

Accessory **A1** x 5PCS
 Accessory **A2** x 20PCS
 Accessory **A11** x 5PCS



Front
 Top

ASSEMBLY INSTRUCTIONS


8

Accessory **A6** x 1PC

Accessory **A7** x 1PC

Accessory **A9** x 3PCS


Accessory **A10** x 6PCS



9

Part **H** x1PC

Hardware **9** x 4PCS




ASSEMBLY INSTRUCTIONS

10

Part **A** x1PC

Hardware **2** x 4PCS

Accessory **A4** x 4PCS




11

Hardware **5** x 1PC

Hardware **6** x 1PC


Hardware **10** x 2PCS



ASSEMBLY INSTRUCTIONS



12

Part **B** x1PC
Hardware ⑦ x 4PCS



13

Hardware ⑦ x 8PCS



ASSEMBLY INSTRUCTIONS

14

ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.




Keep this handy!

Please retain this instruction manual and any order-related information for future reference.




Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.



Compatible with portable charger (not included with this product)



Aim the remote control at the Led controller

