



THE OUTDOOR
GREATROOM
COMPANY

Kenwood Collection Benches

Installation Instructions For:

KW-LB & KW-SB



KW-LB



KW-SB

SAVE THESE INSTRUCTIONS

When using the furnishing, basic precautions should always be followed, including the following:

- Read all instructions before using benches
- Use the furnishing only for its intended use as described in these instructions.

Included in Packaging



Top (1X)

(Top for KW-LB pictured)



Legs (4X)



Touch-Up Paint Bottle (1X)




Hex Wrench (1X)



Assembly Instructions

NOTE: Before assembly, check for damage. Do not use damaged components.

1. Unpack all the contents from the box and remove the individual packaging from each component.
2. Carefully lay the **Top**, with underside facing upwards, on a soft and flat surface.



3. Slide the **legs** over tightening mechanism located in each corner of bench top. Using provided hex wrench, tighten the screws to secure legs to bench top. Do a final tightening of all screws to fully secure legs.



4. Once all legs are secure, flip bench over.



Care and Maintenance Notes:

- Light scratches may be removed from the poly-wood surfaces of this fire pit by gently sanding with 220-grit sandpaper in the same direction as the grain. Sanding too deeply or not following the grain of the material could result in permanent damage.
- Occasional tightening of screws may be required with regular use.



14400 Southcross Drive West • Suite 100 • Burnsville, MN 55306
Toll Free: 1-866-303-4028 • Sales@OutdoorRooms.com

Thank you for purchasing an Outdoor GreatRoom Company product! This product was made with pride in the USA.

