


Dresser

Congratulations on the purchase of your Dresser. This dresser has been crafted to the highest standards of quality and safety and will give you many years of enjoyment and practical use.


Since this dresser is a natural wood product, there will be variations in color and grain, and minor checking may occur. This is normal and does not compromise the integrity of your dresser. In fact, variation in character of solid hardwood is integral to the beauty and appeal of hardwood furniture, and distinguishes it from prefabricated, synthetic and composite materials.

On this insert you will find a list of the hardware and parts included, as well as detailed assembly instructions. Assembly is quite simple, and requires only a Phillips head screwdriver. Assembly will be most easily accomplished if you take the time to carefully sort the hardware and familiarize yourself with the function of each piece.

If you need assistance with assembly, part replacement, or any other matter, please contact the toll-free Customer Service Team. You may also email your request or comments and a customer service representative will respond.




Thank you and Enjoy




Do not turn the handle to tighten or loosen the screw. Doing so will cause the handle to scratch the front of the door. Using a Phillips head screwdriver, remove the handle screw and install the handle on the front of the drawer.

PARTS



Tip-Over Straps Pack

Contains 8 screws, 4 strap brackets and 2 straps





WARNING:

Furniture tipping over can create a significant hazard in the home, particularly to young children, although adults can be injured as well. It is recommended that casegoods over 30" in height be secured with some form of anti-tip over device. This dresser comes with anti-tip over straps that reduce the risk of tipping. These can be easily installed in minutes. We strongly recommend that you use them, especially where children are concerned and where earthquakes may pose a hazard.

If you find you need to remove a drawer, fully extend the drawer, push and hold track tabs in their proper positions as shown below. Then you can remove the drawers.

NOTE: Each drawer is made only for its original location so make sure if you remove more than one they go back in the proper order.

LEFT SIDE HOLD DOWN



RIGHT SIDE HOLD UP

