

LED FLOOR LAMP WITH ADJUSTABLE LIGHT

PACKAGE CONTENTS

- A. Upper Body
- B. Pole
- C. Pole
- D. Pole
- E. Lamp Base
- F. Remote Control

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce risk of electric shock, this plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter this plug. Save these instructions for future reference.

ASSEMBLY AND INSTALLATION INSTRUCTIONS

Start assembly from top to bottom:

1. Screw upper body (A) onto pole (B) clockwise to tighten. Pull any excess cord gently through the poles so that these parts fit.
2. Screw pole (B) into pole (C) clockwise to tighten.
3. Screw pole (C) into pole (D) clockwise to tighten.
4. Screw pole (D) onto lamp base (E) clockwise to tighten.

TOUCH CONTROL


TURN ON/OFF: Long press.

4-COLOR TEMPERATURE SETTING: Short press the button again. 3000K, 4000K, 5000K, 6000K.

BRIGHTNESS SETTING: +/- Slide Up and Down.

REMOTE CONTROL

- Can easily control the floor lamp in a 49.2ft / 15m distance range.
- Remote control is magnetic, can be stored or attached on lamp pole or steel surface.



CARE AND MAINTENANCE

Clean with soft dry cloth. Do not use abrasives.

