

ASSEMBLY INSTRUCTIONS

1. FASTEN THE NECK ONTO LAMP BODY.
BE CAREFUL NOT TO TWIST THE POWER CORD.
2. PLACE THE HARP ONTO SADDLE.
3. PLACE THE SHADE ONTO HARP AND TIGHTEN FINIAL.
4. USE TYPE A BULB NOT MORE THAN 3WAY 100W

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

