


TV Stand

















Thank you for purchasing **TV Stand**

!Before you start, here are some helpful advice:


1. We suggest you spend a short time reading through this leaflet and then follow the simple step-by-step instructions.
2. Owing to the size and weight of the TV Stand, we recommend that it is assembled by two adults, on a carpeted or padded area, in the room that it is intended for. Approximate assembly time: 60 minutes.
3. Please do not use any tools other than those provided or recommended in these instructions.
4. Please do not throw away any of the packaging or instructions until you have checked all the components and hardware and the furniture is fully assembled.
5. Assemble all components loosely until advised to tighten. Depending on use, it may be necessary to tighten the components from time to time, so please save the tools that have been provided.
6. Please keep all pieces out of reach of children.



Hardware :


A) Cambolt/Metal  $\varnothing 6 \times 35 \text{ mm}$ x 10	B) CamLock/Metal  $\varnothing 15 \text{ mm}$ x 10	C) Dowel/Wood  $\varnothing 8 \times 30 \text{ mm}$ x 40	D) Screw/Metal  $M 12 \times 35 \text{ mm}$ x 6	E) Screw/Metal  $M 7 \times 50 \text{ mm}$ x 6
F) Shelf Pin/Metal  $\varnothing 5 \times 15 \text{ mm}$ x 12	G) Screw/Metal  $M 3.5 \times 15.5 \text{ mm}$ x 10	H) Wedge/Plastic  $9 \times 14 \times 10 \text{ mm}$ x 10	I) Foam Pad/Spon  $25 \times 25 \times 2 \text{ mm}$ x 4	J) Key/Metal  $L 4$ x 1
K) Pin Sliding Top/Plastic  $\varnothing 8 \times 19 \text{ mm}$ x 4	L) Buffer/Rubber  $\varnothing 8 \text{ mm}$ x 1	M) Stopper/Plastic  $42 \times 14 \times 8 \text{ mm}$ x 2	N) Pin Sliding Bottom/Plastic  $\varnothing 8 \times 16 \text{ mm}$ x 4	O) Screw Cup/Plastic  $\varnothing 15 \text{ mm}$ x 6
P) x 1  Screwdriver (Not Include)				

Components:




1	Top Board	x1	2	Bottom Board	x1	3	Side Board Left	x1	4	Side Board Right	x1
5	Center Board 1	x1	6	Center Board 2	x1	7	Leg	x2	8	Support Board 1	x2
9	Support Board 2	x2	10	Support Board 3	x1	11	Door	x2	12	Adjustable Shelf 1	x2
13	Adjustable Shelf 2	x1	14	Back Board	x1						



STEP 1:





STEP 2:




STEP 3:





	
Bx2	Px1

Hardware required. Screwdriver not included

STEP 4:





	
Bx2	Px1

Hardware required. Screwdriver not included

STEP 5:



To be continued to Step 8



Cx4


Hardware required

STEP 6:




Hardware required. Screwdriver not included



STEP 7:



STEP 8:





STEP 9:



Fx12

Hardware required

STEP 10:




Kx4

Ox4


Mx2

Hardware required


STEP 11:



STEP 12:



STEP 13:



Assembly is complete. The TV Stand is ready to enjoy now !