


# INSTRUCTION MANUAL



**Lucia Solid Wood Upholsted Side Chair**

## ! NOTICE

### Please keep this instruction for your future reference.

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tighten screws.)

## TOOLS REQUIRED



ALLEN WRENCH  
(PROVIDED)



CHAIR  
65 LBS  
CAPACITY



1 PERSON  
ASSEMBLY



UP TO 60 MIN  
ASSEMBLY

## HARDWARE

1

WOOD DOWEL  
M8 x 30mm



10 PCS

2

JCBC BOLT  
M6 x 40mm



4 PCS

3

SPRING  
WASHER M6



4 PCS

4

FLAT WASHER  
M6 x 13mm



4 PCS

5


PEN HEAD  
SCREW  
M4 x 25mm



4 PCS

6

PEN HEAD  
SCREW  
M4 x 32mm



4 PCS

7

WOOD BUTTON  
10.5mm



4 PCS

8

WOOD BUTTON  
14.5mm



4 PCS

## PARTS

A


FRONT & BACK RAIL



2 PCS

B


LEFT CHAIR SIDE



1 PCS

C

RIGHT CHAIR SIDE



1 PCS

D

BACK TOP



1 PCS

E

CUSHION SEAT




1 PCS

## PRODUCT ASSEMBLY - CHAIR


1

Hammering part 1 wood dowel into Part A, Part B and Part C.




2

Assemble Part A front & back rail to Part B left chair side with 2pcs of part 2 screw, 2pcs of part 3 spring washer and 2pcs of part 4 flat washer. Do not tighten screws too much at this stage.



3


Assemble Part C right chair side to Part A front & back rail with 2pcs of part 2 screw, 2pcs of part 3 spring washer and 2pcs of part 4 flat washer. Do not tighten screws too much at this stage.



## PRODUCT ASSEMBLY - CHAIR


4

Assemble Part D back top to Part B & Part C chair side with 4pcs of part 5 screw.  
Assemble Part 7 wood button into Part B & Part C chair side.



5

Assemble Part E cushion seat to Part B & Part C chair side with 4pcs of part 6 screw.



6

Tighten all the screws again to Part 2 and Part 3.  
Assemble Part 8 wood button into Part B & Part C chair side ensure the dining chair is stable enough to use.

