Double Chaise Lounge
- Instruction Manual

(No Tools Required)

To fully enjoy the comfort and functionality of your new boneless chaise lounge , please follow these steps to help it regain its original shape after unboxing :

1. To avoid damaging the sofa fabric by applying excessive force with ordinary knives, please use our included cutter to gently cut open the plastic bag.

2. Pat the Pillows: Gently pat the pillow on each side several times to assist in reshaping it.

3. Lightly Tap and Press: Lightly tap, knock, and press on the sofa to help it regain its original shape and improve overall comfort.

4. Smooth the Fabric: Our sofa is made of high-quality flannel. Due to the natural texture of the fabric, the color may appear slightly different when brushed in different directions or viewed from different angles. This is a normal characteristic of flannel, it does not indicate a quality issue.

Notice:

1.Please be careful not to get hit by the chaise that opens quickly.

2. Due to compression during packaging for more efficient shipping, the fabric may have wrinkles. These wrinkles will gradually disappear over time.

3. Please be patient and allow the sofa to return to its fully fluffy state, which may take anywhere from 72 hours to one week.

Package Included:

Chaise Lounge x 2 ; Backrest pillow x 2 ; Throw pillow x 2 ; Cutter x 1 ; Instruction Manual x 1

If you experience any issues such as insufficient rebound height, fabric wrinkles, fabric color variance, incorrect sofa orientation, or need assistance, please don't hesitate to contact our customer service team.

Enjoy your new lounge!

